

MUBEA BS 90

Operating Instructions

Transfer or reproduction of this document, use and account of its contents is not permitted., unless express permission is granted. Violators are obliged to pay for damages.

All rights reserved for granting of a patent or registration of an industrial design.

Technical modifications reserved.

Manufacturer: **MHR UND BENDER**
Maschinenbau GmbH
Postfach 340
D- 57427 Attendorn

Introduction

In this user manual you will find all the information required for the installation, startup, operation and maintenance of your reinforcing steel cutting machine BS 90.

Before you start working with the BS 90, please read this user manual thoroughly.


Safety instructions and important notes that must be observed by all means are identified by the following symbols:



This symbol identifies safety instructions that must be heeded by all means, since otherwise persons may be injured or even killed. Furthermore, if they are not heeded, the machine and its functions may be severely damaged.




This symbol identifies a warning against hazardous electric voltage.




This symbol identifies notes with information facilitating your works or the understanding of the procedure described.

For representation purposes, some of the illustrations do not depict the prescribed safety fixtures. When working with the machine, however, these safety fixtures must absolutely be installed!




When working with the BS 90, the safety fixtures must be installed by all means!

Customer service:

 (02722) 62-297

Spare parts and accessories:

 (02722) 62-297

- 1 General Information
- 2 Safety Instructions
- 3 Startup / Shutdown
- 4 Operation
- 5 Adjustment Procedures
- 6 Maintenance Procedures
- 7 Malfunctions and Corrective Maintenance
- 8 Circuit Diagrams and Drawings
- 9 Spare Parts Lists

| Chapter | | Page |
|---------|---|------|
| 1 | General Information | |
| 1.1 | Technical Data | 1 |
| 1.1.1 | Mechanical Specifications | |
| 1.1.2 | Electrical Specifications | 1 |
| 1.1.3 | Ratings | 1 |
| 1.2 | General Description | 2 |
| 1.3 | Operating elements | 3 |
| 2 | Safety Instructions | |
| 2.1 | General Notes | 1 |
| 2.2 | Obligations of the Operator | 2 |
| 2.3 | Proper and Correct Use | 3 |
| 2.4 | Misuse | 3 |
| 2.5 | Safety Instructions | 4 |
| 3 | Startup / Shutdown | |
| 3.1 | Transport | 1 |
| 3.1.1 | Transport by crane | 1 |
| 3.1.2 | Transport by fork lift | 1 |
| 3.1.3 | Transport by Truck or Train | 2 |
| 3.2 | Installation | 2 |
| 3.3 | Power Connection | 3 |
| 3.4 | Final Inspection prior to Startup | 3 |
| 3.5 | Mechanical Aspects | 4 |
| 3.6 | Shurtdown | 4 |
| 4 | Operation | |
| 4.1 | Preparatory Procedures | 1 |
| 4.2 | Switching on the Machine | 1 |
| 4.3 | Operating the Reinforcing Steel Cutting Machine | 1 |
| 4.3.1 | Notes on Safety | 1 |
| 4.3.2 | Single-Stroke Safeguarding Device | 2 |
| 4.3.3 | Using the Reinforcing Steel Cutting Machine | 2 |
| 5 | Adjustment Procedures | |
| 5.1 | Reinforcing Steel Cutting Machine | 1 |
| 5.1.1 | Steady | 2 |
| 6 | Maintenance | |
| 6.1 | Cleaning the machine | 1 |
| 6.2 | Blades | 1 |
| 6.3 | Clutch | 4 |
| 6.4 | Lubrication | 6 |
| 6.5 | Adjustment of the slide guide | 7 |
| 7 | Malfunctions and Corrective Maintenance | 1 |
| 8 | Circuit Diagrams and Drawings | |

9 Spare Parts Lists

1

General Information

1 GENERAL INFORMATION

1.1 Technical Specifications

Machine type: BS 90
 Machine number:
 Model:
 Sound level: 75 db (A)

1.1.1 Mechanical Specifications

Weight: 435 kg
 Gross weight (packed seaworthy): 590 kg
 Dimensions (L x W x H): 1115 x 450 x 710

1.1.2 Electrical Specification

Motor type: 4 AP 100 L-4
 Motor power: 3 kW
 Power consumption: 6,37 A
 Operating voltage: 400V Y; 50 c/s
 Rpm: 1430 min⁻¹

1.1.3 Ratings

The following table lists the ratings of the BS 90

| Anzahl der Stäbe Number of bars Nombre de Barres | ∅ 1 mm | ∅ 2 mm | ∅ 3 mm | ∅ 4 mm | □ 1 mm | □ 2 mm | □ 3 mm | □ 4 mm | Flach- stahl mm |
|--|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|-----------------------|
| Betonstahl 850 N/mm ² | 28 | 20 | 16 | 14 | 24 | 18 | 14 | 12 | 75 x 8 |
| Reinforcing steel 650 N/mm ² | 32 | 22 | 18 | 16 | 28 | 20 | 16 | 14 | 75 x10 |
| Fers a beton 450 N/mm ² | 40 | 28 | 20 | 18 | 34 | 24 | 20 | 16 | 75 x14 |
| Schnitte Cuts per min min ⁻¹ Coupes | 60 | | | | | | | | |

1.2 General Description

The Reinforcing Steel Cutting Machine BS 90 is a heavy-duty machine constructed in a robust and failure-immune style.


The double-edged blades are manufactured of high-grade tool steel. The adjustable-steady in the form of a planar cam guides the rods to their correct cutting position. The operating elements of the machine are described in Section 1.3.

The scope of delivery includes:

- Reinforcing steel cutting machine BS 90
- 1 concrete steel blade
- 1 tool kit

Supplementary special equipment can be ordered from Muhr und Bender.

For more detailed information, please revert to our customer service.




[BS90-1]

Legend:

- | | | | |
|---|-------------------------|---|------------------|
| 1 | Material support roller | 5 | Power connection |
| 2 | Steady | 6 | Foot switch |
| 3 | Protective cover | | |
| 4 | Blade | | |

1.3 Operating Elements

Overview of the positions of the operating elements described in detail on the following pages:



[BS90-2]

Legend:

- A Power connection
- B Power switch
- C Foot switch
- D Lubrication
- E Material rollers

Power Connection (A)

The BS 90 is connected via the connector supplied.



The connection to the power supply must be performed by an electrician!




[BS90-5]

Power switch (B)

Positions:

| | |
|---|-----|
| I | On |
| O | Off |

In the "Off" position, all the machine's phases are disconnected from the power supply.



[BS90-5]




In the "Off" position, the supply lines still carry voltage. For this reason, the machine must be disconnected from the external power supply whenever repair works are to be performed on the electrics.

Foot switch (C)

The BS 90 is equipped with a foot switch that sends the signal for initiating the cutting process.

The shear slide will automatically perform a shearing movement. The foot switch must be actuated for each cut.



[BS90-16]



The safety fixtures must not be removed. Prior to switching the machine on, they must always be checked for completeness and proper attachment. Damaged safety fixtures must be replaced.

Lubrication (D)

The machine is equipped with a centralized oil lubrication.


The machine is lubricated using the manual lubrication pump (refer to Chapter 6.4 "Lubrication").



[BS90-3]

Material Rollers (E)

The material can be pulled slightly forward via the material transport rollers - not in the blade opening - since this can easily damage the cutting edges, especially when ripped bars are cut.



[BS90-8]

2

Safety Instructions

2. SAFETY INSTRUCTIONS

2.1 General Notes

This User Manual contains general notes that must be observed for the installation, startup, operation and maintenance of the machine.

For this reason it must be read by mechanical engineers and the skilled personnel involved prior to the machine's installation and startup.


The User Manual must be available at the machine's operation site at all times.

The machine operator has the permanent obligation to observe the overall technical condition of the machine (externally visible defects and damage, modification of the operating behaviour).

The operator is obliged to immediately report any changes on the machine or its operational behaviour that may impair safety.

For operating the machine, the local safety instructions and regulations for preventing accidents must equally be observed.

The Identification of Instructions and Notes in the User Manual



This symbol identifies safety instructions that must be heeded by all means, since otherwise persons may be injured or even killed. Furthermore, if they are not heeded, the machine and its functions may be severely damaged.



This symbol identifies a warning against hazardous electric voltage.



This symbol identifies notes with information facilitating your work or the understanding of the procedure described.

Dangers

When operated by untrained personnel or when used improperly or for purposes not complying with its design and intended field of application, this machine may be a hazard.

Danger Zone

When cutting long reinforcing steel rods, a danger zone is created. This danger zone must be sufficiently safeguarded against unauthorized access. A clearance distance must be kept to other machines, devices and other obstacles.

Use

The machine has been designed and constructed for a specific purpose.

If the machine is used in a way in which it was not intended to be used (misused), the manufacturer takes no liability for any consequential damage. The risk lies solely with the operator.

Refrain from any procedures impairing the safety of the operator or the machine.

Warning and Notice Signs on the Machine

Warning and notice signs directly affixed to the machine, such as arrows indicating the direction of rotation, must be observed by all means and must be kept in perfectly legible condition.

2.2 Obligations of the Operator

Qualification and Training of the personnel

The personnel performing the installation, startup, maintenance and inspection operations must be appropriately qualified for these procedures.

If the personnel is not sufficiently qualified, it must be trained and instructed accordingly.


In addition, ensure that the personnel reads the present User Manual and completely understands the information contained therein.

Dangers arising from the Non-Observance of the Safety Instructions

If the safety instructions are not observed, persons, the environment and the machine may be endangered.

Non-observance of the safety instructions leads to the loss of all claims for damage.

Noise Protection



The sound level of the machine is below 75 dB (A). For this reason, hearing protectors are not mandatory.

Due to environmental influences, e.g. on a construction site in combination with other machines, however, this value can be exceeded. In this case, the operating personnel must wear appropriate hearing protectors.

The operator is responsible for the availability of appropriate hearing protectors and must make sure that the personnel uses them.

Unauthorized Modification and Manufacture of Spare Parts

Modification or rebuilding of the machine is impermissible.

Originally supplied spare parts and accessories guarantee the operator's safety.

The use of other parts voids all liability of Muhr und Bender for any consequential damage. .

Impermissible Misuse

The machine's operational safety can be guaranteed only if the machine is operated in a way that corresponds to the purpose it has been designed and constructed for and in keeping with Section 2.3 of this User Manual.

The performance data specified in Section 1.1.3 must not be exceeded.

2.3 Proper and Correct Use

The proper and correct use of the machine is restricted to cutting reinforcing steel.

The performance data of the machine must not be exceeded (refer to Section 1.1.3 "Ratings").

Any use other than the above-described or exceeding it is regarded as improper use or misuse.

The operating place of the operator is on the front (operation side) of the reinforcing steel cutting machine.

2.4 Misuse

The following is regarded as improper use (misuse):

- Any application differing from the use stated above or any application exceeding it.
- The non-observation of the notes and instructions on safety.
- When malfunctions or defects that may impair safety are not eliminated before continuing the operation of the machine.
- Any manipulation of the machine facilities that serve for trouble-free functioning and operation, unlimited use and active and passive safety of the machine.
- If the machine is not operated in technically integer condition, in consideration of safety and hazards and under observation of the pertinent instructions outlined in the User Manual e.g.
 - * wrong direction of rotation of the motor, e.g. due to incorrect electrical connection
 - * machine not installed solidly



Misuse of the machine voids all liability and warranty of the manufacturer!

2.5 Safety instructions

General Notes



Misuse of the machine voids all liability and warranty of the manufacturer!



Works on the electrics must be performed by an electrician!



Any special tools used must be designed as safe tools.

Instructions Relating to the Protective Covers



Protective Covers must be mounted before the machine is operated!



Safety fixtures must not be removed!
Prior to switching the machine on, they must always be checked for completeness and proper mounting. Damaged safety fixtures must be replaced.

Instructions Relating to the Power Switch



In the "Machine Off" position, the supply lines still carry voltage. For this reason, the machine must be disconnected from the external power supply whenever repair or maintenance works are to be performed.

Instructions Relating to Blades and Tools



Blades and tools must be reground in due time.
Blunt cutting edges affect the machine performance and produce unclean cuts.



Worn blades and tools must not be used.



Periodically check the blades and tools for blunt or jagged cutting edges.



The blade clearance must be checked with each change of the blade.



Unclean cuts leave burrs and jagged spikes on the workpiece and thus increase the risk of injury.

Safety Fixtures



Safety fixtures must not be removed. Prior to switching the machine on, they must always be checked for completeness and proper mounting. Damaged safety fixtures must be replaced.

Safety fixtures on the front of the machine.



Notes on Transporting the Machine



When transporting the machine, ensure that cables and supply lines are not bent or jammed.



The lifting power of the crane, straps, ropes and lifting equipment must be rated for the weight of the machine (refer to the section on Technical Specifications).



Never step under hanging loads.



Do not place the straps around the machine housing.



To prevent damage, transport the machine only with a board platform screwed to its bottom.




Tighten the ring bolt thoroughly.

Notes on Installing the Machine



When installing the machine, ensure that cables and supply lines are not bent or jammed.



The connection to the power supply must be performed by an electrician.

Notes on Maintenance and Cleaning of the Machine




Disconnect the power switch prior to performing any maintenance procedures.

3

Startup and
Shutdown

3. STARTUP / SHUTDOWN

3.1 Transport



When transporting the machine, ensure that cables and supply lines are not bent or jammed.

3.1.1 Transport by crane

- Ensure that the ring bolt is tightened thoroughly.
- Transport the machine only at the ring bolt provided for this purpose.



[BS90-1c]




The lifting power of the crane, ropes, chains and lifting equipment must be rated for the weight of the machine (refer to Section 1.1 "Technical Specifications").
Never step under hanging loads.
Always tighten ring bolts thoroughly.

3.1.2 Transport by Fork Lift

- Screw the machine onto a stable board platform so that it can be lifted with the fork lift when positioned in longitudinal direction.
- Lift the machine in longitudinal direction only to prevent the machine from tilting.




To prevent damage, transport the machine by fork lift only with a stable board platform screwed to its bottom.



3.1.3 Transport by Truck or Train


Screw the machine onto a solid board platform so that it is stable (in Germany, the moving company is responsible for fastening the machine thus prepared properly on the freight car or truck; please check the applicable local laws for information on this topic).



3.2 Installation

The machine has a standard operating height. For this reason, the operating height need not be adjusted by means of platforms or subbases.

Before installing the machine, check whether the floor of the installation site is sufficiently level and solid.



When installing the machine, ensure that cables and supply lines are not bent or jammed.

3.3 Power Connection



The connection to the power supply must be performed by an electrician!

- Check the mains voltage at the installation site!
- The machine is equipped with an undervoltage no-close release. The machine can thus be switched on only if voltage is applied.

Power Connector

- Connect the power coupling to the power connector of the machine.



3.4 Final Inspection Prior to Startup


- Check the machine for stability.
- Check the motor's direction of rotation.
- If required, have an electrician correct the direction of rotation (refer to Chapter 9, "Circuit Diagrams").



Works on the electrics must be performed by an electrician!

3.5 Mechanical Aspects

- Check the machine for stability.
- Check the safety fixtures for completeness, safe attachment and functioning.
- Verify that the working slide of the machine works properly and that all tools have been adjusted correctly. For this purpose, the Start and Stop switches of the motor must be actuated briefly - with the foot switch closed - to enable engagement of the clutch.
- To move the slide, turn the flywheel in the direction indicated by the arrow and simultaneously engage the clutch.
- Lubricate the machine.



The safety fixtures must not be removed.
Prior to switching the machine on, they must always be checked for completeness and proper attachment.
Damaged safety fixtures must be replaced.

3.6 Shutdown

- Switch off the machine.
- Disconnect the power plug.

No further measures are required for the shutdown.

4

Operation

4. OPERATION

4.1 Preparatory Procedures

- * Check the safety fixtures for safe attachment and functioning
- * Verify that the tools are undamaged and in good condition, that they are mounted safely and that their cutting edges are sharp.

4.2 Switching on the machine

- * Set the power switch (A) to "I".



4.3 Operating the Reinforcing Steel Cutting Machine

4.3.1 Notes on Safety



Worn blades and tools must not be used. Periodically check the blades and tools for blunt or jagged cutting edges.

4.3.2 Single-Stroke Safeguarding Device

The single-stroke safeguarding device prevents a repetition of the cutting stroke even if the clutch remains in its engaged position.

Every actuation of the foot switch always triggers one single cutting stroke only.




If the single-stroke safeguarding device is defective it is possible that the cutting machine performs cutting strokes repeatedly!

4.3.2 Using the Reinforcing Steel Cutting Machine


- Observe the pertinent safety regulations
- Switch on the machine (refer to section 4.2).
- Verify the the steady is adjusted correctly for the thickness of the material to be cut. If required, adjust the steady to an optimum position according to Section 5.
- Place the material on the material support roller and position it correctly.



[BS90-1c]




Pull the material over the transport roller, not through the blade opening, since this may damage the cutting edges.



[BS90-8]

- Actuate the foot switch to trigger the cutting stroke.
- After initiating the cutting stroke, release the foot switch. The shearing slide will perform one cutting stroke and then idle in its home position.
- Periodically check the cutting clearance (refer to Section 5).




[BS90-1b]

5


Adjustment Procedures

5. ADJUSTMENT PROCEDURES


5.1 Reinforcing Steel Cutting Machine




The safety fixtures must not be removed. Prior to switching the machine on, they must always be checked for completeness and proper attachment. Damaged safety fixtures must be replaced.




The machine is not electrically dead! Perform maintenance and adjustment procedures only when the power switch is in its "Off" position and secured against unauthorized access.



Worn blades and tools must not be used.



The steady must be adjusted such that the material is as perpendicular as possible to the blades.




The blade clearance must be checked with each change of the blade.

5.1.1 Steady


- Lift up the steady (A).
- Turn the steady to the desired position.
- Let the steady lock into place.



The steady must be adjusted such that the material is as perpendicular as possible to the blades.



[BS90-11]




[BS90-12]

6

Maintenance

6. MAINTENANCE

6.1 Cleaning the machine



Disconnect the power switch prior to performing any maintenance procedures! The machine is not electrically dead. Perform maintenance and adjustment procedures only when the power switch (A) is in its "Off" position and secured against unauthorised access.

- The BS 90 cutting machine must be cleaned daily.
- Remove scale and corrosion.

When the machine is shut down for an extended period of time, grease the shearing slide and blades to prevent corrosion.

6.2 Blades



Periodically check the blades and tools for blunt or jagged cutting edges.



Blades must be replaced in due time. Blunt cutting edges affect the machine performance and produce unclean cuts.



Unclean cuts leave burrs and jagged spikes on the workpiece and thus increase the risk of injury.




The safety fixtures must not be removed. Prior to switching the machine on, they must always be checked for completeness and proper attachment.

Damaged safety fixtures must be replaced.




Warning and danger signs must not be removed.

Damaged, scratched or illegible warning or danger signs must be replaced with new ones.



For all works within the range of the cutting tools, the power to the machine must be switched off via the power switch (A).
Secure the power switch with a padlock!




The machine is not electrically dead. Perform maintenance and adjustment procedures only when the power switch (A) is in its "Off" position and secured against unauthorized access.

The blades are suitable for cutting all types of reinforcing steel up to a strength of 850 N/mm² (refer to chapter 1, General Information, Section 1.1.3).



Prestressing wire cannot be cut!

When replacing the blades, be sure to mount the new blades correctly. The cutting edges must slide past each other (refer to the illustration).



It is also important to ensure smooth bearing surfaces. If these are damaged, they must be flattened before mounting the new tool.



Be sure to use blades originally provided by MUBEA only.


Only the blade surfaces are reground to ensure an identical blade clearance (the gap between the two blades).

The removal and mounting of the blades is very easy:

- First, remove the blade screw in the body.
- Take out the stationary blade.
- Rotate the flywheel until slide is up front.
- Remove the blade screw and take out the moving blade.

For inserting and mounting the blade, follow the reverse procedure.

The following illustration shows the insertion and mounting of the blades for various material diameters.



Material up to Ø 32 mm

Material from Ø 32 - 40 mm



6.3 Clutch

The machine is equipped with a robust and reliable rolling key clutch.

With the clutch disengaged, the eccentric shaft (A) is in the rear deadcenter position of the slide, while the clutch disk rotates on its shaft journal.

When the engaging device is actuated, the rolling key stop (C) is released. The tensile force of the spring (D) pulls the rolling key to the engagement position and thus interlocks the eccentric shaft (A) and the clutch disk.


Since the rolling key stop (B) swivels back when the engagement device is released, the rolling key will be disengaged after a full rotation of the eccentric shaft, while the clutch disk continues to rotate.



If you hear a clicking sound after an extended operating period, the eccentric brake must be adjusted.

The adjustment screw of the brake can be accessed through the opening on the top of the clutch-disk protective cover (see the figure on the left).

If - for any reason (power failure, blown fuse of the like) - the cutting machine stops during the cutting operation, the motor must be switched off immediately.




In the "Machine Off" position, the supply lines still carry voltage. For this reason, the machine must be disconnected from the external power supply whenever repair or maintenance works are to be performed.

If material is in the feed opening of the blades when the machine is switched off, the machine is under extreme compressive strain.

To relieve the machine of this strain, first remove the protective covers and then rotate the flywheel in reverse direction; this measure also rotates the clutch disk in reverse direction. The rolling key will be pressure-relieved and can be swiveled out. When it is in this position, hold the rolling key at its strap, switch on the motor and let the flywheel and transmission accelerate to full speed. After the rolling key is released, it will lock into place and the cutting operation can be terminated.

If the machine stopped due to overload (material cross sections too large, material strength too high), the machine must be checked for damage.

If it operates flawlessly, it can be smoothly operated manually by rotating the flywheel with the cutting slide engaged. If you feel any sluggishness during this operation, the machine must be checked by a MUBEA mechanical engineer.



6.4 Lubrication

All lubricating points of the machine are combined on one single lubricating strip.




Lubrication instructions/Recommended Lubricants

The following lubricants (oils) are suitable for your cutting machine:

| Brand/Designation | Viscosity |
|------------------------------|---------------------------------|
| ARAL-Deganit B 220 | 220 mm ² /s at 40° C |
| SHELL-Tonna Oil T 220 | 220 mm ² /s at 40° C |
| MOBIL OIL AG-VACTRA Oil Nr.4 | 212 mm ² /s at 40° C |
| ESSO AG-MILLCOT K 220 | 230 mm ² /s at 40° C |
| BP-Energol HP - C 220 | 220 mm ² /s at 40° C |

Lubrication Intervals:

To guarantee trouble-free operation and minimum wear, each lubricating point must be filled with 2 pump strokes of lubricant (approx. 1,5 cm³) twice per day.



When lubricated, the machine must be at a standstill.


If the running noise of the gearwheels increases they (clutch wheel and intermediate gear) must be greased with gearwheel grease ESSO SURETT FLUID 4k.

6.5 Adjusting the Slide Guide


The slide (Fig. 16, Position A) of the reinforcing steel cutting machine moves on guide rails made of a special material. The slide guide can be adjusted on the face side of the machine as well as in traverse direction. This guarantees for a clearance-free movement.

On the face side, the following adjustment procedures need to be performed:

- Loosen the setscrews (B) on the left side of the machine.
- Tighten the pressure screws (C) by clockwise rotating them from above until you can feel a clear resistance, then loosen them again by 1/8th of a turn to the left.
- Retighten the setscrew (B).



[BS90-16]




The safety fixtures must not be removed!
Prior to switching the machine on, they must always be checked for completeness and proper attachment. Damaged safety fixtures must be replaced.



In the "Machine Off" position, the supply lines still carry voltage. For this reason, the machine must be disconnected from the external power supply whenever repair or maintenance works are to be performed.

The adjustment in traverse direction is performed on the left side of the machine (refer to Fig. 17) by performing the following steps:

- Remove the locking screws (D).
- Tighten the dowel pins (E and F) by clockwise rotating them until you can feel a clear resistance, then loosen them again by 1/8th of a turn to the left.
- Pin the setscrews (D) and tighten them.



[BS90-17a.tif]

7

Malfunctions and
Corrective
Maintenance

Malfunctions and Corrective Maintenance

| Malfunction | Cause | Corrective Maintenance |
|--|--|---|
| Motor does not run | Power supply interrupted | Plug the power connector, set the power switch to „ON“ |
| | Protective motor switch tripped | Let the motor cool down, activate the protective motor switch |
| | Foot switch is not operating properly | Have an electrician find and correct the malfunction |
| | Fuse in supply line tripped | Replace fuse, revert to an electrician, if required |
| | Motor starting contactor defective | Have an electrician find and correct the malfunction |
| Motor switches off after a brief period of operation | Protective motor switch not set correctly or defective | Have an electrician check and - if required - replace the protective motor switch |
| | The limits of the machine's power range were exceeded | Use material with a lower tensile strength/with a lower rod diameter |
| | Motor damaged | Have the motor repaired or replaced |
| Shearing slide does not move on actuation of the foot switch | Foot switch is not operating properly | Have an electrician find and correct the malfunction |
| Shearing slide moves but the workpiece is not being cut | The limits of the machine's power range were exceeded | Use material with a lower tensile strength/with a lower rod diameter |
| | Extremely excessive blade clearance | Set the blade clearance to the specified value |
| | Cutting edges extremely worn or damaged | Replace the blades |

8

Wiring diagrams and
drawings (included in
the switch box)

Spare part lists

ERSATZTEILLISTE Modell BS 90 – 30051

| | Baugruppe |
|-------------------------------|------------------|
| Körper, kpl. | 30021 001 00 |
| Schwungradwelle, kpl. | 30021 002 00 |
| Exzenterwelle, kpl. | 30021 003 00 |
| Druckstück, kpl. | 30021 004 00 |
| Scherenschlitten, kpl. | 30021 005 00 |
| Handeinrückung, kpl. | 30021 006 00 |
| Betonstahlmesser, kpl. | 30051 001 00 |
| Gegenhalter, kpl. | 30021 008 00 |
| Elektrische Einrichtung, kpl. | 30051 002 00 |
| Handschmierung, kpl. | 30021 010 00 |
| Schutzhaube, kpl. | 30051 003 00 |
| Zubehörwerkzeuge, kpl. | 30019 012 00 |
| Fußeinrückung, kpl. | 30021 014 00 |

PARTS LIST Model BS 90 – 30051

| | Assembly |
|-----------------------------------|-----------------|
| Machine body, complete | 30021 001 00 |
| Flywheel shaft, complete | 30021 002 00 |
| Eccentric shaft, complete | 30021 003 00 |
| Pressure piece, complete | 30021 004 00 |
| Shear slide, complete | 30021 005 00 |
| Hand engagement, complete | 30021 006 00 |
| Reinforcing steel knife, complete | 30051 001 00 |
| Counter-holder, complete | 30021 008 00 |
| Electric system, complete | 30051 002 00 |
| Hand lubrication, complete | 30021 010 00 |
| Guard, complete | 30051 003 00 |
| Tool kit, complete | 30019 012 00 |
| Foot engagement, complete | 30021 014 00 |


LISTE DES PIECES DE RECHANGE Modèle BS 90 – 30051

| | Groupe |
|--------------------------------|---------------|
| Bâti compl. | 30021 001 00 |
| Arbre de volant compl. | 30021 002 00 |
| Arbre excentrique compl. | 30021 003 00 |
| Pièce de pression compl. | 30021 004 00 |
| Coulisseau de cisailage compl. | 30021 005 00 |
| Embrayage à main compl. | 30021 006 00 |
| Lames pour fer à béton compl. | 30051 001 00 |
| Contre-support compl. | 30021 008 00 |
| Partie électrique compl. | 30051 002 00 |
| Graissage manuel compl. | 30021 010 00 |
| Capôt de protection compl. | 30051 003 00 |
| Outils accessoires compl. | 30019 012 00 |
| Embrayage à pédale compl. | 30021 014 00 |



Muhr und Bender
MASCHINENBAU GMBH


D-5952 Attendorn · Postfach 340 · Telefon (02722) 62-1
Telex 876 706-0 mu d · Teletex 27 223 512 · Telefax (02722) 62-499



| Pos. Item Rep. | Artikel-Nr. Part No. Article-No. | Stck./Masch. Piece/Page Piéce-Mach. | Benennung | Denomination | Désignation |
|----------------|----------------------------------|-------------------------------------|-------------------------|-------------------------------------|----------------------------|
| 1.1 | 30021 001 01 | 1 | Körperplatte, komplett | Machine frame, front side, complete | Plaque d'assemblage compl. |
| 1.2 | 30021 001 13 | 1 | Deckplatte, komplett | Cover plate, complete | Couvercle compl. |
| 2 | 30021 001 17 | 1 | Gleitstück, oben | Gib, top | Glissière, supérieure |
| 3 | 30021 001 18 | 1 | Gleitstück, unten | Gib, lower | Glissière, inférieure |
| 4 | 30021 001 19 | 2 | Führungsstopfen, kurz | Guide plug, short | Bouchon de guidage court |
| 5 | 30021 001 20 | 1 | Führungsstopfen, lang | Guide plug, long | Bouchon de guidage long |
| 6 | 907 513 1100 | 3 | Sechskantscheidschraube | Hex. cutting screw | Vis 6 pans |
| 7 | 30019 001 20 | 2 | Druckschraube | Pressure screw | Vis de pression |
| 8 | 900 913 4300 | 2 | Gewindestift | Slotted set screw | Goujon fileté |
| 9 | 900 580 1500 | 1 | Ringschraube | Eye bolt | Vis circulaire |
| 10 | 900 610 4100 | 5 | Paßschraube | Adjusting screw | Vis |
| 11 | 30021 001 21 | 1 | Paßschraube | Adjusting screw | Vis |
| 12 | 900 610 4200 | 2 | Paßschraube | Adjusting screw | Vis |
| 13 | 30021 001 22 | 1 | Paßschraube | Adjusting screw | Vis |
| 14 | 900 936 3100 | 9 | Sechskantmutter | Hex. nut | Ecrou hexagonal |
| 15 | 901 481 3100 | 1 | Spannstift | Roll pin | Goupille élastique |
| 16 | 30021 001 23 | 1 | Auflagerolle, komplett | Support roller, complete | Rouleau de support compl. |
| 16.1 | 30021 001 24 | 1 | Lagerbock, komplett | Bearing support, complete | Support porte-rouleaux |
| 16.2 | 30019 001 27 | 1 | Achse | Axle | Axe |
| 16.3 | 30019 001 28 | 3 | Führungsrolle | Feed roller | Rouleau de guidage |
| 16.4 | 900 914 2300 | 1 | Gewindestift | Slotted set screw | Vis sans tête |
| 16.5 | 900 610 4300 | 2 | Paßschraube | Adjusting screw | Vis |
| 16.6 | 900 936 3100 | 2 | Sechskantmutter | Hex. nut | Ecrou hexagonal |
| 17 | 810 600 4330 | 4 | Rhombusrolle | Lozenge roller | Rouleau Rhombus |
| 18 | 901 440 5100 | 4 | Blanke Scheibe | Bright washer | Disque |
| 19 | 900 471 3400 | 4 | Sicherungsring | Circlip | Anneau de sécurité |
| 20 | 30021 001 28 | 1 | Buchse | Bush | Coussinet |
| 21 | 900 551 5400 | 1 | Gewindestift | Slotted set screw | Vis sans tête |

Schwungradwelle, komplett
Flywheel shaft, complete
Arbre de volant compl.


30021 002 00



| Pos. Item Rep. | Artikel-Nr. Part No. Article-No. | Stck./Masch. Piecе/Page Pièce-Mach. | Benennung | Denomination | Désignation |
|----------------------|--|---|------------------------|---------------------------|----------------------------------|
| 1 | 30021 002 01 | 1 | Lagergehäuse, komplett | Bearing housing, complete | Corps de palier, compl. |
| 1.1 | 30021 002 02 | 1 | Lagergehäuse | Bearing housing | Corps de palier |
| 1.2 | 900 625 1400 | 3 | Ring-Rillienlager | Deep groove ball bearing | Roulement rainuré à billes |
| 1.3 | 810 600 0070 | 2 | Niilos-Ring | Bearing seal | Bague «Niilos» |
| 1.4 | 05010 011 02 | 2 | Lagerdeckel | Bearing cover | Couvercle de palier |
| 1.5 | 900 933 2080 | 8 | Sechskantschraube | Hex. screw | Vis à tête hexagonale |
| 1.6 | 30021 002 03 | 1 | Schwungradwelle | Flywheel shaft | Arbre de volant |
| 2 | 810 600 1040 | 4 | Zylinderschraube IP | Slotted head screw IP | Vis à tête cylindrique fendue IP |
| 3 | 810 600 0020 | 4 | DUBO-Sicherung | DUBO-Washer | Pièce de sécurité |
| 4 | 30021 002 04 | 1 | Schwungrad | Flywheel | Volant |
| 5 | 906 885 5400 | 1 | Paßfeder | Key | Ressort de contact |
| 6 | 30021 002 05 | 1 | Deckscheibe | Cap | Pastille |
| 7 | 906 912 4030 | 1 | Zylinderschraube | Slotted head screw | Vis à tête cylindrique fendue |

Exzenterwelle, komplett
Eccentric shaft, complete
Arbre excentrique compl.



30021 003 00



| Pos. Item Rep. | Artikel-Nr. Part No. Article-No. | Stck./Masch. Piece/Page Pièce-Mach. | Benennung | Denomination | Désignation |
|----------------|----------------------------------|-------------------------------------|--------------------------------|-----------------------------------|--|
| 1 | 30021 003 01 | 1 | Exzenterwelle | Eccentric shaft | Arbre excentrique |
| 2 | 30021 003 02 | 1 | Flanschlager, komplett | Flanged bearing housing, complete | Palier à bride compl. |
| 2.1 | 30021 003 03 | 1 | Flanschlager | Flanged bearing housing | Palier à bride |
| 2.2 | 30021 003 04 | 1 | Buchse für Flanschlager | Bush for flanged bearing housing | Coussinet pour palier à bride |
| 2.3 | 900 551 5400 | 1 | Gewindestift | Slotted set screw | Vis sans tête |
| 3 | 810 600 1170 | 4 | Zylinderschraube IP | Slotted head screw IP | Vis à tête cylindrique fendue IP |
| 4 | 810 600 0020 | 4 | DUBO-Sicherung | DUBO-Washer | Pièce de sécurité |
| 5 | 30021 003 05 | 1 | Kupplungsrad, komplett | Gear, complete | Roue d'accouplement compl. |
| 5.1 | 30021 003 06 | 1 | Kupplungsrad | Gear | Roue d'accouplement |
| 5.2 | 05010 012 08 | 1 | Kupplungsnahe | Hub | Moyeu d'embrayage |
| 5.3 | 906 885 5700 | 2 | Paßfeder | Key | Clavette |
| 6 | 30021 003 07 | 1 | Kupplungsring, außen, komplett | Outer coupling ring, complete | Bague d'accouplement, ext. compl. |
| 6.1 | 05010 012 11 | 1 | Kupplungsring, außen | Outer coupling ring | Bague d'accouplement, ext. |
| 6.2 | 05010 012 12 | 1 | Buchse | Bushing | Douille |
| 6.3 | 900 551 5400 | 2 | Gewindestift | Slotted set screw | Vis sans tête |
| 6.4 | 906 885 3100 | 1 | Paßfeder | Key | Clavette |
| 7 | 30021 003 08 | 1 | Innenkupplung, komplett | Inner coupling, complete | Embrayage interieur compl. |
| 7.1 | 30021 003 09 | 1 | Kupplungsring, innen, komplett | Inner coupling ring, complete | Bague d'accouplement, int. compl. |
| 7.1.1 | 30021 003 10 | 1 | Kupplungsring, innen | Inner coupling ring | Bague d'accouplement, int. |
| 7.1.2 | 05010 012 12 | 1 | Buchse | Bushing | Douille |
| 7.1.3 | 900 551 5400 | 2 | Gewindestift | Slotted set screw | Vis sans tête |
| 7.2 | 30021 003 11 | 1 | Exzenterbremse, komplett | Eccentric brake, complete | Frein excentrique compl. |
| 7.2.1 | 05010 015 01 | 1 | Bremsband, komplett | Brake band, complete | Bande de frein compl. |
| 7.2.2 | 05010 015 04 | 1 | Gabelbolzen | Yoke pin | Boulon à fourche |
| 7.2.3 | 900 007 0600 | 1 | Zylinderstift | Straight pin | Goupille cylindrique |
| 7.2.4 | 05010 015 05 | 1 | Gewindebolzen | Set screw | Boulon fileté |
| 7.2.5 | 900 084 5600 | 1 | Zylinderschraube | Slotted head screw | Vis à tête cylindrique à 6 pans creux |
| 7.2.6 | 05010 015 06 | 1 | Druckfeder | Pressure spring | Ressort de pression |
| 7.2.7 | 906 885 3500 | 1 | Paßfeder | Key | Clavette |
| 8 | 05010 012 15 | 1 | Schaftschraube | Shaft bolt | Vis à tige |
| 9 | 05010 012 16 | 1 | Zugfeder | Tension spring | Ressort de traction |
| 10 | 30021 003 12 | 1 | Drehkeil, komplett | Rolling key, complete | Clavette tournante compl. |
| 10.1 | 05010 012 17 | 1 | Drehkeil | Rolling key | Clavette tournante |
| 10.2 | 05010 013 16 | 1 | Anschlagleiste | Rolling key lever | Regle de butée |
| 10.3 | 900 912 2030 | 1 | Zylinderschraube | Slotted head screw | Vis à tête cylindrique à 6 pans creux |
| 11 | 05010 012 19 | 1 | Deckscheibe | Cap | Pastille |
| 12 | 810 600 1180 | 2 | Zylinderschraube IP | Slotted head screw IP | Vis à tête cylindrique à 6 pans creux IP |
| 13 | 810 600 0030 | 2 | DUBO-Sicherung | DUBO-Washer | Pièce de sécurité |

| | |
|--------------------------------|--------------|
| Druckstück, komplett | 30021 004 00 |
| Scherenschlitten, komplett | 30021 005 00 |
| Pressure, piece, complete | 30021 004 00 |
| Shear slide, complete | 30021 005 00 |
| Pièce de pression compl. | 30021 004 00 |
| Coulisseau de cisailage compl. | 30021 005 00 |


| |
|--------------|
| 30021 004 00 |
| 30021 005 00 |




| Pos. Item Rep. | Artikel-Nr. Part No. Article-No. | Stck./Masch. Piece/Page Pièce-Mach. | Benennung | Denomination | Désignation |
|----------------------|--|---|------------------------|--------------------------|--------------------------------|
| 1 | 30021 004 00 | 1 | Druckstück, kpl. | Pressure piece, complete | Pièce de pression compl. |
| 1.1 | 30021 004 01 | 1 | Druckstück | Pressure piece | Pièce de pression |
| 1.2 | 30021 004 03 | 1 | Buchse | Bushing | Douille |
| 1.3 | 900 551 5400 | 1 | Gewindestift | Socket set screw | Vis sans tête |
| 2 | 30021 005 00 | 1 | Scherenschlitten, kpl. | Shear slide, complete | Coulisseau de cisailage compl. |
| 2.1 | 30021 005 01 | 1 | Scherenschlitten | Shear slide | Coulisseau de cisailage |
| 2.2 | 30021 005 02 | 4 | Führungsstück | Guide | Guide |
| 2.3 | 900 963 3200 | 4 | Senkschraube | Countersunk screw | Vis à tête fendue |

Handeinrückung, komplett
 Hand engagement, complete
 Embrayage à main compl.


30021 006 00




| Pos. Item Rep. | Artikel-Nr. Part No. Article-No. | Stck./Masch. Piece/Page Pièce-Mach. | Benennung | Denomination | Désignation |
|----------------------|--|---|-------------------------|--------------------------|-----------------------------|
| 1 | 30021 006 01 | 1 | Einrückhebel, komplett | Handlever, complete | Levier d'embrayage compl. |
| 1.1 | 30019 006 02 | 1 | Drehbolzen | Pivot shaft | Axe |
| 1.2 | 30021 006 02 | 1 | Aufnahmehebel, komplett | Trip arm lever, complete | Bras de butée levier compl. |
| 1.3 | 900 471 3100 | 1 | Sicherungsring | Retaining ring | Bague de sécurité |
| 1.4 | 30021 006 05 | 1 | Anschlagarm | Trip arm | Bras de butée |
| 1.5 | 05010 041 06 | 1 | Druckfeder | Pressure spring | Ressort de pression |
| 1.6 | 810 600 0150 | 1 | Zapfenfeder | Spring | Clavette |
| 1.7 | 900 934 3500 | 1 | Sechskantmutter | Hex. nut | Ecrou hexagonal |
| 1.8 | 901 481 0700 | 1 | Spannstift | Roll pin | Goupille élastique |
| 1.9 | 30019 006 09 | 2 | Einrückstange | Engagement rod | Tige d'embrayage |
| 1.10 | 900 319 6100 | 2 | Kugelknopf | Ball knob | Boiton sphérique |
| 1.11 | 900 934 2500 | 2 | Sechskantmutter | Hex. nut | Ecrou hexagonal |
| 1.12 | 971 802 0500 | 1 | Winkelgelenk | Angle joint | Articulation d'equerre |
| 2 | 05029 045 02 | 1 | Gewindestift | Eye screw | Vis sans tête |
| 3 | 05011 045 03 | 1 | Zugfeder | Tension spring | Ressort de traction |
| 4 | 900 933 2570 | 1 | Sechskantschraube | Hex. cap screw | Vis à tête hexagonal |
| 5 | 900 934 2500 | 1 | Sechskantmutter | Hex. nut | Ecrou hexagonal |
| 6 | 901 481 4500 | 2 | Spannstift | Roll pin | Goupille élastique |
| 7 | 901 481 4900 | 1 | Spannstift | Roll pin | Goupille élastique |
| 8 | 901 481 0400 | 1 | Spannstift | Roll pin | Goupille élastique |




| Pos. Item Rep. | Artikel-Nr. Part No. Article-No. | Stck./Masch. Piece/Page Pièce-Mach. | Benennung | Denomination | Désignation |
|----------------------|--|---|------------------|-------------------------|-------------------------------|
| 1 | 501 370 0000 | 2 | Betonstahlmesser | Reinforcing steel knife | Lames pour fer à béton |
| 2 | 906 912 4020 | 1 | Zylinderschraube | Slotted head screw | Vis à tête cylindrique fendue |
| 3 | 906 912 4040 | 1 | Zylinderschraube | Slotted head screw | Vis à tête cylindrique fendue |
| 4 | 05010 055 03 | 2 | Tellerfeder | Spring washer | Rondelle ressort |
| 5 | 501 690 0000 | 1 | Betonstahlmesser | Reinforcing steel knife | Lames pour fer à béton |



| Pos. Item Rep. | Artikel-Nr. Part No. Article-No. | Stck./Masch. Piece/Page Pièce-Mach. | Benennung | Denomination | Désignation |
|----------------------|--|---|------------------------|-------------------------|--------------------------|
| 1 | 30021 008 01 | 1 | Bolzen zum Gegenhalter | Bolt for counter-holder | Boulon du contre-support |
| 2 | 30021 008 02 | 1 | Gegenhalter | Counter-holder | Contre-support |
| 3 | 901 481 5500 | 1 | Spannstift | Roll pin | Goupille élastique |
| 4 | 900 471 3400 | 1 | Sicherungsring | Retaining ring | Bague de sécurité |




| Pos. Item Rep. | Artikel-Nr. Part No. Article-No. | Stck./Masch. Piece/Page Pièce-Mach. | Benennung | Denomination | Désignation |
|----------------------|--|---|------------------------|---------------------|--------------------------------|
| 1 | 810 100 6880 | 1 | Motor mit Schalter | Motor with switch | Moteur avec interrupteur |
| 2 | 810 100 1150 | 1 | CEE-Kupplungssteckdose | CEE-coupling socket | Socle de prise de couplage CEE |
| 3 | 30051 002 01 | 1 | Motorconsole | Motor bracket | Console du moteur |
| 4 | 900 933 3090 | 4 | Sechskantschraube | Hex. cap screw | Vis à tête hexagonal |
| 5 | 900 125 2700 | 4 | Scheibe | Washer | Rondelle plate |
| 6 | 900 933 4580 | 2 | Sechskantschraube | Hex. cap screw | Vis à tête hexagonal |
| 7 | 900 125 4400 | 2 | Scheibe | Washer | Rondelle plate |
| 8 | 900 933 3640 | 1 | Sechskantschraube | Hex. cap screw | Vis à tête hexagonal |
| 9 | 05010 071 01 | 1 | Motorriemenscheibe | Vee belt pulley | Poulie moteur |
| 10 | 05010 071 02 | 1 | Deckscheibe | Cap | Pastille |
| 11 | 900 933 2560 | 1 | Sechskantschraube | Hex. cap screw | Vis à tête hexagonal |
| 12 | 902 215 2920 | 2 | Keilriemen | Vee belt | Courroie trapezoidal |



| Pos. Item Rep. | Artikel-Nr. Part No. Article-No. | Stck./Masch. Piece/Page Pièce-Mach. | Benennung | Denomination | Désignation |
|----------------------|--|---|---|---|--|
| 1 | 30021 010 01 | 2 | Stehbolzen | Stud bolt | Boulon fileté |
| 2 | 811 100 1890 | 1 | Schmiernippelleiste | Lubricating nipple strip | Listeau de graisseurs |
| 3 | 900 912 2030 | 2 | Zylinderschraube | Socket head screw | Vis à tête cylindrique à 6 pans creux |
| 4 | 811 100 1600 | 1 | Drehanschluß | Rotary fitting | Raccord articulé |
| 5 | 901 481 1700 | 2 | Spannstift | Roll pin | Goupille élastique |
| 6 | 811 100 0090 | 2 | Einschraubwiderstandsventil mit Dichttring | Screwed resistance value with packing ring | Soupape à résistance filetée avec rondelle de joint |
| 7 | 811 100 0070 | 1 | Hydraulischer Schmiernippel | Hydraulic lubrication nipple | Graisseur pour système hydraulique |
| 8 | 811 100 0080 | 1 | Gummikappe | Rubber cap | Capuchon en caoutchouc |
| 9 | 811 100 0100 | 1 | Einschlagnippel | Drive-in nipple | Graisseur à enfoncer |
| 10 | 811 100 0030 | 10 | Winkel-Einschraubverschraubung | Elbow connector | Graisseur d'equerre |
| 11 | 811 100 0050 | 4 | Gerade Einschraubverschraubung | Straight connector | Raccord droit |
| 12 | 811 100 0840 | 1 | Schwenkverschraubung | Swivel connector | Raccord pivotant |
| 13 | 811 100 0620 | 8,5 m | Tecalan-Rohr 4/2 | Tecalan tubing, 4/2 | Tube Tecalan 4/2 |
| 14 | 811 100 0600 | 16 | Einsteckhülse 4/2 | Sleeve 4/2 | Sleeve 4/2 |
| 15 | 972 571 1100 | 1 | Befestigungsschelle | Clip | Clip |
| 16 | 972 571 1300 | 4 | Befestigungsschelle | Clip | Clip |
| 17 | 972 573 1000 | 1 | Befestigungsschelle | Clip | Clip |
| 18 | 972 573 1200 | 2 | Befestigungsschelle | Clip | Clip |
| 19 | 972 573 1800 | 3 | Befestigungsschelle | Clip | Clip |
| 20 | 810 600 0140 | 17 | POP-Blindniet | »POP« blind rivet | Rivet |

Schutzhaube, komplett
 Guard, complete
 Capôt de protection compl.

30051 003 00








| Pos. Item Rep. | Artikel-Nr. Part No. Article-No. | Stck./Masch. Pièce/Page Pièce-Mach. | Benennung | Denomination | Désignation |
|----------------------|--|---|------------------------------|----------------------|--|
| 1 | 30051 003 01 | 1 | Schutzhaube für Kupplungsrad | Coupling wheel guard | Capôt de protection pour la roue d'embrayage |
| 2 | 900 912 3100 | 5 | Zylinderschraube | Socket head screw | Vis à tête cylindrique à 6 pans creux |
| 3 | 900 933 3030 | 5 | Sechskantschraube | Hex. cap screw | Vis à tête hexagonal |
| 4 | 30051 003 02 | 1 | Abdeckung | Covering | Couverture |
| 5 | 30051 003 03 | 1 | Schutzhaube für Schwungrad | Flying wheel guard | Capôt de protection pour roue volant |
| 6 | 30019 011 05 | 3 | Winkel | Angle | Cornières |
| 7 | 30019 011 06 | 1 | Deckblech | Cover | Tôle de protection |
| 8 | 900 084 4100 | 10 | Zylinderschraube | Socket head screw | Vis à tête cylindrique à 6 pans creux |
| 9 | 05050 091 07 | 1 | Abdeckscheibe | Cover | Pastille |
| 10 | 810 600 0140 | 1 | POP-Blindniet | »POP«-blind rivet | Rivet |


Zubehörwerkzeuge, komplett

Tool, kit, complete

Outils accessoires compl.

30019 012 00

| <i>Größe</i> | <i>Artikel-Nr.</i> | <i>BS 90</i> |
|---|--------------------|--------------|
|  | | |
| 5 | 900 911 2000 | 1 |
| 8 | 900 911 2600 | 1 |
| 14 | 900 911 3200 | 1 |
|  | | |
| 13 | 900 894 2400 | 1 |
| 30 | 900 894 4000 | 1 |
|  | | |
| 17 x 19 | 900 895 3200 | 1 |
|  | | |
| - | 810 600 0740 | 1 |
|  | | |
| Nr. 2 | 811 100 1090 | 1 |
| <i>Putzlappen</i> | | |
| - | 810 600 0260 | 1 |



| Pos. Item Rep. | Artikel-Nr. Part No. Article-No. | Stck./Masch. Piece/Page Pièce-Mach. | Benennung | Denomination | Désignation |
|----------------------|--|---|--------------------|----------------------|---------------------------------------|
| 1 | 30019 014 01 | 1 | Gelenkhebel | Angle lever | Levier d'articulation |
| 2 | 30019 014 02 | 1 | Scheibe | Washer | Rondelle plate |
| 3 | 901 445 2100 | 1 | Bolzen | Bolt | Axe |
| 4 | 30021 014 02 | 1 | Zugstab | Connecting rod | Tige de traction |
| 5 | 971 802 0500 | 2 | Winkelgelenk | Angle joint | Articulation d'equerre |
| 6 | 30021 014 01 | 1 | Zugstab | Connecting rod | Tige de traction |
| 7 | 971 802 0100 | 1 | Winkelgelenk | Angle joint | Articulation d'equerre |
| 8 | 30019 014 05 | 1 | Fußhebel, komplett | Foot pedal, complete | Levier au pied compl. |
| 9 | 30019 014 08 | 1 | Hebelhalter | Pedal bracket | Porte levier |
| 10 | 906 912 2050 | 2 | Zylinderschraube | Socket head screw | Vis à tête cylindrique à 6 pans creux |
| 11 | 30019 014 09 | 1 | Gewindebolzen | Pivot pin | Boulon avec fileté |
| 12 | 900 934 3100 | 1 | Sechskantmutter | Hex. nut | Ecrou hexagonal |