

**3 PT MOUNTED PLANTER  
OPERATOR & PARTS  
MANUAL**

**M0102**

**1984**

# WARRANTY

---

The KINZE® Limited Warranty for your new machine is stated on the back of the retail purchaser's copy of the Warranty And Delivery Report form.

Warranty, within the warranty period, is provided as part of KINZE's support program for registered KINZE® products which have been operated and maintained as described in this manual. Evidence of equipment abuse or modification beyond original factory specifications will void the warranty. Normal maintenance, service and repair is not covered by KINZE® warranty.

To register your KINZE® product for warranty, a Warranty And Delivery Report form must be completed by the KINZE® Dealer and signed by the retail purchaser, with copies to the Dealer, to the retail purchaser and to KINZE Manufacturing, Inc. Registration must be completed and sent to KINZE Manufacturing, Inc. within 30 days of delivery of the KINZE® product to the retail purchaser. KINZE Manufacturing, Inc. reserves the right to refuse warranty on serial numbered products which have not been properly registered.

Additional copies of the Limited Warranty can be obtained through your KINZE® Dealer.

If service or replacement of failed parts which are covered by the Limited Warranty are required, it is the user's responsibility to deliver the machine along with the retail purchaser's copy of the Warranty And Delivery Report to the KINZE® Dealer for service. KINZE® warranty does not include cost of travel time, mileage, hauling or labor. Any prior arrangement made between the Dealer and the retail purchaser in which the Dealer agrees to absorb all or part of this expense should be considered a courtesy to the retail purchaser.


*KINZE® warranty does not include cost of travel time, mileage, hauling or labor.*

# TO THE OWNER

---


We at Kinze Manufacturing wish to thank you for your patronage and appreciate your confidence in Kinze farm machinery. Your Kinze Planter has been carefully designed and sturdily built to provide years of dependable operation in return for your investment.

This manual has been prepared to aid you in the assembly, operation, and maintenance of the planter. Refer to it when necessary to maintain the machine in efficient operating condition.

Throughout this manual the symbol  and the words **Note**, **Caution** and **Warning** are used to call your attention to important safety information. The definition of each of these terms used, follows:

**NOTE:** Indicates a special point of information.

**CAUTION:** Indicates that a failure to observe can cause damage to the machine or equipment.

 **WARNING:** Indicates that a failure to observe can cause damage to equipment and/or personal injury.

This manual is applicable to:

3 Pt. Mounted Planter - Model Number MT

Serial Number 15723 and on

Record the model number and serial number of your planter with date purchased below:

Date Purchased \_\_\_\_\_

Serial Number \_\_\_\_\_

Model Number \_\_\_\_\_



# TABLE OF CONTENTS

---

<b>New Machine Warranty</b> .....	1
<b>Introduction</b> .....	2
General Information .....	2
Serial Number .....	2
<b>Safety Precautions</b> .....	3
<b>Assembly</b> .....	4
Hardware .....	4
Torque Values Chart .....	4
Frame Assembly .....	4
Final Inspection .....	6
<b>Lubrications</b> .....	7
Sealed Bearings .....	7
Chains .....	7
Wheel Bearings .....	7
Lubrication Chart .....	7
<b>Operations</b> .....	8
Initial Preparation of Planter .....	8
Mounted Planter Attachment .....	8
Transporting the Planter .....	8
Leveling the Planter .....	8
Transmission Adjustment .....	9
Tire Pressure .....	9
Hydraulic Marker Operation .....	9
Marker Adjustment .....	9
Tractor Speed .....	9
Plateless Corn Meter Planting Rates .....	10
Plateless Soybean Meter Planting Rates .....	11
Plateless Regular Rate Sorghum Meter Planting Rates .....	12
Plateless Low Rate Sorghum Meter Planting Rates .....	13
Plate Type Drive Planting Rates .....	14-15
Dry Insecticide Application Rates .....	16
Dry Herbicide Application Rates .....	17
<b>Maintenance</b> .....	18
Mounting Bolts and Hardware .....	18
Chain Tension Adjustment .....	18
Flow Control Inspection .....	18
Sequencing Valve Inspection .....	18
Wheel or Marker Bearing Lubrication or Replacement .....	19
Preparation for Storage .....	19
<b>Parts List Index</b> .....	20
<b>Numerical Index</b> .....	40



# NEW MACHINE WARRANTY

No warranties express or implied are made or will be deemed to have been made by Kinze of the products sold under this Agreement except as follows:

Kinze warrants to the original purchaser for use that if any part of the product proves to be defective in material or workmanship within one year from date of original purchase, and is reported to Kinze within 10 days after such defect is discovered, Kinze will (at our option) either replace or repair said part. Return of the defective part to Kinze and submission of a completed warranty request must be accomplished within 30 days of the date that the replacement is made available.

This warranty does not apply to damage resulting from misuse, neglect, accident or improper installation or maintenance. A part will not be considered defective if it substantially fulfills performance specifications. Labor, shipping, field service, travel or administrative expenses incurred in connection with warranty replacements are not covered. Tires are not warranted by Kinze Manufacturing, Inc. and such claims must be pursued through the tire manufacturer's warranty.

Kinze warrants all replacement parts for a period of 90 days from date of purchase by the customer. Parts warranty is subject to the same provisions, restrictions and exclusions as new machine warranty and carries the same return and reporting requirements.

The foregoing warranty is exclusive and in lieu of all other warranties or merchantability, fitness for purpose and of any other type, whether express or implied. Kinze neither assumes nor authorizes anyone to assume for it any other obligation or liability other than stated above, and will not be liable for consequential damages. Purchaser accepts these terms and warranty limitations unless the product is returned within the fifteen days for full refund of purchase price.

Kinze reserves the right to make changes or to add improvements at any time without notice or obligations.

ATTENTION: Effective 12/1/87  
amendments were made to the  
Kinze New Machine Warranty.  
Refer to insert W12187.

# INTRODUCTION

---

The 3 point mounted planter is available with a choice of 40", 38", 36" or 30" row spacing, dry herbicide and insecticide application equipment and heavy duty coulters. For information on installation and use of optional equipment on all models, refer to the assembly and operation section of this manual or the Kinze Row Unit Manual.

## General Information

The information and photos used in this manual were current at the time of printing. However, due to Kinze's continual attempt to improve its product, in-line production changes may cause your machine to appear slightly different in detail. Kinze Manufacturing reserves the right to change specifications or design without notice and without incurring obligation to install the same on machines previously manufactured.

Right hand or left hand as used throughout this manual is determined by facing in the direction the machine will travel when in use unless otherwise stated.

## Serial Number

The serial number provides important information about your planter and may be required to obtain the correct replacement part.

The serial number plate is located on the planter frame to be readily available. It is suggested that the serial number and purchase date also be recorded in the space provided on the inside front cover of this manual. Always provide the serial number and model number to your Kinze dealer when ordering parts or anytime correspondence is made with Kinze Manufacturing.





# SAFETY PRECAUTIONS

Safe and careful operation of the tractor and planter at all times will contribute significantly to the prevention of accidents.

Since a large portion of farm accidents occur as a result of fatigue or carelessness, safety practices should be of utmost concern. Read and understand the instructions provided in this manual as well as those provided in your row unit operator's manual. Listed below are a few other safety suggestions that should become common practice.

- Never permit any persons other than the operator to ride on the tractor.
- Never ride on the planter frame or allow others to do so.
- Always make sure there are no persons near the planter when gauge marker assemblies are in operation.
- Always lower the planter when not in use and cycle the hydraulic control lever to relieve pressure in cylinders and hoses.
- Always make necessary safety preparations prior to transporting the machine on public roads. This includes installing Slow Moving Vehicle (SMV) emblem and use of adequate lights or safety warnings after dark, except where prohibited by law.
- Watch for obstructions such as wires, tree limbs, etc., when folding marker assemblies.
- Always install marker lock up/safety pins before transporting or parking any planter equipped with conventional marker assemblies.

("Safety" Position Shown)



## DANGER

THIS PLANTER IS DESIGNED TO BE DRIVEN BY GROUND TIRES ONLY. THE USE OF HYDRAULIC, ELECTRIC OR PTO DRIVES MAY CREATE SERIOUS SAFETY HAZARDS TO YOU AND THE PEOPLE NEAR BY. IF YOU INSTALL SUCH DRIVES YOU MUST FOLLOW ALL APPROPRIATE SAFETY STANDARDS AND PRACTICES TO PROTECT YOU AND OTHERS NEAR THIS PLANTER FROM INJURY.

## WARNING

THIS MACHINE HAS BEEN DESIGNED AND BUILT WITH YOUR SAFETY IN MIND. ANY ALTERATION TO THE DESIGN OR CONSTRUCTION MAY CREATE SAFETY HAZARDS. DO NOT MAKE ANY ALTERATIONS OR CHANGES TO THE EQUIPMENT, BUT IF ANY ALTERATIONS OR CHANGES ARE MADE YOU MUST FOLLOW ALL APPROPRIATE SAFETY STANDARDS AND PRACTICES TO PROTECT YOU AND OTHERS NEAR THIS MACHINE FROM INJURY.

# ASSEMBLY

The following instructions are provided for assembly of the Kinze 3 Point Mounted Planter. Please read through the instructions prior to assembly. Becoming familiar with the procedures before actual set up will facilitate smoother assembly and possibly save time by eliminating backtracking. Although there may be procedures for assembly other than those shown, caution should be taken to avoid unnecessary risk to compensate for the extra time to safely perform each step.



Prior to starting, inspect all components for possible damage incurred during shipment. Notify the freight or carrier agent immediately of any damage found. Any parts shortages should be noted and reported to Kinze Manufacturing, Inc. immediately.

Since the assembly instructions which follow are written for several sizes and configurations of units, they are divided into major components which are interchangeable. The interchangeability designed into each Kinze planter simplifies assembly as well as operation, service, and parts availability for any size and model unit.

## Hardware

All bolts furnished with the planter are SAE Grade 5 unless otherwise noted. The 8 bolts used to mount the markers are SAE Grade 2 for added shear protection. All bolts are distinguished by the radial lines on the bolt head. (See chart)

In many cases bolts have been pre-instilled in the holes in which they go during assembly. It is suggested that bolts be left somewhat loose until parts have been assembled. This especially applies to bearing flanges, idlers, etc. Then tighten all bolts to the torque value specified below unless otherwise noted.

DRY TORQUE VALUES - FT. LBS.		
Bolt Diameter	Grade 2 No Radial Lines 	Grade 5 Three Radial Lines 
5/16"	11	17
3/8"	23	35
1/2"	55	85
5/8"		170
3/4"		360
1"		670
1 1/4"		910

**NOTE:** Bolts having lock nuts should be tightened to approximately 50% of amounts shown in chart. Also bolts lubricated prior to installation should be torqued to 70% of value shown on chart.



# FRAME ASSEMBLY

1. Place the partially assembled planter shipping bundle in your selected assembly area.
2. Unband the planter shipping bundle and inspect for damage.

Each bundle should contain:

- A. Basic frame assembly
- B. Two marker assemblies
- C. Two marker blades

Also open the two boxes containing the hydraulic hoses and hardware.



# ASSEMBLY

3. While supporting the frame, remove the bolts which fasten the frame to the skid. Carefully lower the planter frame assembly to a horizontal position.

4. Lower parking stands to support the planter.

**NOTE:** Depending upon the planter size the planter is equipped with either single or double folding markers.

5. Mount the marker assemblies to the planter frame.

A. Single fold markers are preassembled with the exception of the marker disc. Bolt the single fold marker assembly to the mounting pad using four 1/2" x 2" Grade 2 cap screws, lock washers and hex nuts on each side. Install markers so that spindles project forward.

**⚠ WARNING:** Always leave the marker assembly laying in the horizontal position or secure it with the safety lock up pin, when the markers are in up position.

B. On planters using double fold markers, bolt the first stage with the preassembled cylinder to the mounting pad using four 1/2" x 2" Grade 2 cap screws, lock washers and hex nuts on each side.


C. Attach the pre-assembled second stage with pivot pin and cotter pins. Install markers so that spindles project forward.

**NOTE:** We recommend that you do not connect the rod end of the cylinder to the second stage until the hydraulic hoses have been assembled and cycled.

6. Remove the plugs from all cylinder ports. Depending upon the planter model you are assembling, see hydraulic section pages in the parts section of this manual for fitting and hose information.

**NOTE:** Refer to dual or single valve system as applicable.

7. Mount left hand valve plate assembly on left side of center section and right hand valve plate assembly on right hand side of center section using holes provided.



8. Secure hydraulic hoses to planter with nylon tie straps.

9. Install customer supplied coupler on tractor end of each hose. The couplers installed must be the SAE type to match the tractor being used.

10. Prime the hydraulic system.

**⚠ CAUTION:** Disconnect the rod end of both marker cylinders before cycling the cylinders. The flow control valves must be adjusted to prevent damage to the marker assembly. Loosen the lock nut on each knurled adjustment knob and screw the adjustment all the way closed. Open each valve approximately 1/2 turn. Cycle the hydraulic system several times with the cylinder rods disconnected to purge all air from the hydraulic system. After the cylinders are operating smoothly, attach the rod end of each cylinder.

11. The sequencing valve on single valve systems is used to alternate the marker raise and lowering automatically.

12. The flow control valves are used to regulate the speed of the marker.

# ASSEMBLY

---

**⚠ WARNING:** Always stand clear of the marker assemblies when in operation.

13. Attach the 16" disc to the hub using the preinstalled bolts. Be sure to alternate bolts while tightening to avoid distorting the disc's shape or breaking the marker hub.

**NOTE:** The marker disc is installed so the concave side of the disc is outward to throw dirt away from the grease seals. The spindle bracket is slotted so the hub and blade can be angled to throw more or less dirt.

**⚠ WARNING:** Always position marker lock up pin in "safety" position when transporting or storing the planter. See Safety Precaution.

## 14. Marker Adjustment

To determine the correct length at which to set the marker assemblies, multiply the number of rows by the row spacing in inches. This provides the total planting width. Then adjust the marker extension so that the distance from the marker disc to the center line of the planter is equal to the total planting width previously obtained. Both the planter and marker assembly should be lowered to the ground when measurements are being taken. Also, the measurement should be taken from the point where the disc contacts the ground. Adjust right and left marker assemblies equally and securely tighten clamping bolts. An example of marker length adjustment follows:

---


Number of Rows X Row Spacing (Inches) =	Dimension between planter center line and marker blade
6 x 30" = 180" marker dimension	

---

**Make a final inspection of the assembled planter.**

---

- Lubricate per instructions.
- Check for loose hydraulic hoses and fittings.
- Check for loose bolts, nuts, etc.
- Check all drive chains for proper alignment and tension.
- Make sure all drive shafts and idlers rotate freely and do not bind.
- Make sure all row units are mounted properly and that they are squared on the frame.
- Cycle hydraulics to insure all the air has been purged from the hydraulic system.



# LUBRICATION

This page shows the location of all lubrication points. Proper lubrication of all moving parts will help insure efficient operation of your Kinze Planter and prolong the life of friction producing parts. Those parts equipped with grease fittings should be lubricated at the frequency indicated with an SAE multipurpose type grease. Be sure to clean the fitting thoroughly before using grease gun. The frequency of lubrication recommended is based on normal operating conditions. Severe or unusual conditions may require more frequent attention.

## Sealed Bearings

A number of sealed bearings are used on your Kinze Planter to provide trouble free operation. These are located in such areas as the drive shaft, row units, and transmission bearings. Sealed bearings are lubricated for life, and due to the seals, relubrication is not practical.

## Drive Chains


The transmission and row unit drive chains should be lubricated approximately every 8-10 hours with a quality engine oil or equivalent SAE 10 weight oil. A good quality spray lubricant may also be used for periodic chain lubrication. Extreme operating conditions such as dirt, temperature, or speed may require more frequent lubrication. If any of the chains become stiff, it should be removed and soaked and washed in solvent to loosen and remove dirt from the joints. Then soak the chain in oil so the lubricant can penetrate between the rollers and bushings.

## Wheel Bearings


Wheel bearings should be repacked with clean heavy duty axle grease approximately once a year or at the beginning of each planting season. This applies to all drive wheels and marker hubs. Follow the procedure outlined for wheel bearing replacement with the exception that bearings and bearing caps are reused.

## LUBRICATION CHART


Ref. No.	Description	No. of Zerks	Frequency
1.	Idler Sleeve (Transmission)	1	10 Hours
2.	Low Profile Double Folding Marker	2 (Per marker)	10 Hours
3.	Conventional Marker	2 (Per marker)	10 Hours



1. Idler Sleeve (Transmission)



2. Low Profile Double Folding Marker Assembly.



3. Conventional Marker Assembly

# OPERATION

The following information is general in nature and was written to aid the operator in preparation of the tractor and planter for use, and to provide general operating procedures. The operator's experience, familiarity with the machine and the following information should combine for efficient planter operation and good working habits. The operator's manual for the row units used with your Kinze Planter should also be readily available and consulted for planter operation.

## Initial Preparation of the Planter

Lubricate the planter and row units per the lubrications information in this manual and the row unit operator's manual. Make sure all tires have been properly inflated. Check all drive chains for proper tension and lubrication.


## Mounted Planter Attachment

1. Tractor front end stability is necessary for safe efficient operation. Therefore, it may be necessary to add front ballast to your tractor for satisfactory field operation, as well as adequate transport stability. Refer to your tractor operator's manual for front ballast recommendations.
2. Adjust the length of the lift links.
3. Back tractor up to planter and raise draft links between hitch plates. Line up holes and insert hitch pins. Lock hitch pins in place with pins provided.
4. Connect center link to planter mast. It may be necessary to change the length of the center link with the adjusting handle.
5. Connect hydraulic hoses to tractor ports in a sequence that is both familiar and comfortable to the operator.

Before attaching hoses, move remote hydraulic levers back and forth to relieve any pressure in the tractor hydraulic system.

**IMPORTANT: Always wipe hose ends to remove any dirt before connecting couplers to tractor ports.**

**Caution: Before the gauge markers are hydraulically operated, make sure that all hydraulic hoses are properly connected and marker lock-up pins are in working position.**



6. Raise planter slowly and watch for any interference. Remove pin from each support stand and raise each to the transport position. Secure stands in raised position with pin in lowest hole.
7. Lower planter so that drive wheels rest on ground and check for planter levelness. Readjust top link as required to level row units.

**Caution: As a general safety practice and to avoid damage to the tractor hydraulic system, always lower the planter when not in use.**

## Transporting The Planter

Always make necessary safety preparations prior to transporting the planter on public roads. This includes installing Slow Moving Vehicles (SMV) emblem and use of adequate lights or safety warning after dark.

## Leveling The Planter

For proper operation of the planter and row units, it is important that the unit operate level.


When operating the mounted planter, make sure the right and left arms are adjusted equally before attaching the planter unit. After the planter has been lowered to the correct operating depth, stop the tractor and stand behind the planter to check for level operation laterally. Then walk around to the side and check fore and aft levelness. If the row units seem to angle up or downward, adjust the center link on the tractor accordingly.

In order to maintain lateral levelness, it is important that tire pressure be maintained at pressures specified.

# OPERATION

## Transmission Adjustment

The transmission is designed to allow simple and rapid changes in sprocket combination to obtain the desired planting population. Since both the transmission drive shaft and the row unit drive shaft are hexagonal in shape, the sprockets need only be slid into alignment with the idlers after first removing the rubber spacers and loosening the drive chain. The combination of small sprockets may require shortening the drive chain.



A decal positioned next to the transmission and the information provided in your row unit operator's manual or planting rate charts in this manual will aid you in the selection of the correct sprocket combinations. After positioning both sprockets, replace rubber spacers between sprockets or on the ends as necessary. Then restore tension on the drive chain.

## Tire Pressure

Tire pressure should be checked regularly and maintained as follows:

Drive Gauge - 7:60 x 15" 4-Ply-40 PSI

**IMPORTANT:** Tire pressure must be correctly maintained in all drive wheel tires to insure levelness and proper operation of planter. All rate charts are based on rolling radius of 7:60 x 15 tires inflated to 40 PSI.

## Hydraulic Marker Operation

**WARNING:** Always stand clear of the gauge marker assembly and blade when it is in operation.

**CAUTION:** The flow controls should be properly adjusted before the marker assembly is first put into use to prevent equipment damage.

To properly match the marker cylinder speed to your tractor's hydraulic system, loosen the lock nut which secures the knurled adjustment knob in place. To increase the cylinder speed turn the valve counterclockwise, opening the valve. To decrease the cylinder speed turn the valve clockwise.

**NOTE:** Marker speed will decrease with cold oil supply. Make sure that all adjustments are made with warm oil. Do not overtighten locknut.

**WARNING:** Always position marker lock-up pin in "Safety" position when transporting or storing planter. See Safety Precaution.

## Marker Adjustment

We recommend a field test be made to insure the markers are properly adjusted. After the field test is made, make any minor adjustments necessary.

## Tractor Speed

Planters are designed to operate within a speed range of 2 to 7 M.P.H. Optimum speed for most conditions is 5 to 6 M.P.H. Rate charts provided in this manual and in the Kinze Row Unit Manual are based on this optimum speed.

Variations in ground speed will produce variations in rates. Corn meter populations will tend to be disproportionately higher at high ground speeds. Soybean and sorghum seed cup populations will tend to be disproportionately lower.

We recommend a field test be made to insure proper seed placement and operation of row units.

After the planter has been field tested, reinspect the unit.

- Hoses - Fittings
- Bolts - Nuts
- Drive Chains

**NOTE:** The planter drive line is protected with shear pins. If seed meters on row units fail to operate, check shear pins.

# OPERATION

## PLANTING RATE FOR PLATELESS CORN METERS

Seed Populations Per Acre			Average Seed Placement In Inches	Sprocket Combinations		Recommended Speed Range In MPH
30 Inch Rows	36 Inch Rows	38 Inch Rows		Drive Sprocket	Driven Sprocket	
56,200	46,800	44,300	3-3/4	30	14	2 to 3
48,700	40,600	38,510	4-1/4	26	14	2 to 3 1/2
43,700	36,400	34,500	4 3/4	30	18	3 to 4
41,300	34,400	32,600	5 1/8	22	14	3 to 4 1/2
37,800	31,600	29,900	5 1/2	26	18	3 to 4 1/2
35,700	29,800	28,200	5 7/8	30	22	3 to 5
32,100	26,800	25,400	6 1/2	22	18	3 to 5 1/2
30,700	25,800	24,400	6 3/4	26	22	3 to 6
30,100	25,200	23,900	7	30	26	3 to 6
29,950	24,950	23,700	7 1/8	16	14	3 to 6
27,800	23,200	21,950	7 1/2	30	28	4 to 6 1/2
26,200	21,900	20,600	8	22	22	4 to 7
24,300	20,300	19,200	8 5/8	26	28	4 to 7
23,300	19,400	18,400	9	16	18	4 to 7
22,200	18,500	17,600	9 1/2	22	26	4 to 7
20,700	17,200	16,300	10 1/8	22	28	4 to 7
20,400	16,900	16,100	10 1/4	14	18	4 to 7
19,100	15,900	15,100	11	16	22	4 to 7
16,700	13,950	13,200	12 5/8	14	22	4 to 7
16,200	13,500	12,800	13	16	26	4 to 7
14,950	12,500	11,900	14	16	28	4 to 7
14,200	11,800	11,200	14 7/8	14	26	4 to 7
13,200	10,950	10,400	16	14	28	4 to 7

Above chart for planters equipped with 7.60-15 inch drive tires and 1:1 drive sprocket ratios. Recommended tire pressure 40 PSI.

**IMPORTANT: The above sprocket combinations are best for average conditions. Changes in sprocket combinations may be required to obtain desired planting population.**

The size and shape of seeds will effect the planting rate. Medium round corn is generally the most preferred while small flat is the least desirable. Higher than optimum speeds may result in population rate increases or higher incidents of doubles and triples, particulary with small flat seeds.

**IMPORTANT: To prevent planting miscalculations, make field checks to be sure you are planting at the desired rate.**



# OPERATION

## PLANTING RATE FOR PLATELESS SOYBEAN METERS

Approximate Pounds Per Acre					Sprocket Combinations		Recommended Speed Range In MPH
Rows					Drive Sprocket	Driven Sprocket	
10"	15"	18"-20"	30"	36"-40"			
375	250	196	125	98	30	14	3 to 5
330	220	176	110	88	26	14	3 to 5
300	200	160	100	80	30	18	3 to 5
288	192	152	96	76	22	14	3 to 5
276	184	146	92	73	26	18	3 to 5
258	172	136	86	68	30	22	3 to 5
234	156	122	78	61	22	18	3 to 5½
225	150	118	75	59	26	22	3 to 6
216	144	116	72	58	30	26	3 to 6
213	142	114	71	57	16	14	3 to 6
201	134	106	67	53	30	28	4 to 6½
189	126	100	63	50	22	22	4 to 7
174	116	92	58	46	26	28	4 to 7
165	110	88	55	44	16	18	4 to 7
162	108	86	54	43	22	26	4 to 7
150	100	80	50	40	22	28	4 to 7
147	98	78	49	39	14	18	4 to 7
144	96	76	48	38	16	22	4 to 7
129	86	68	43	34	14	22	4 to 7
123	82	66	41	33	16	26	4 to 7
120	80	64	40	32	16	28	4 to 7
111	74	60	37	30	14	26	4 to 7
105	70	56	35	28	14	28	4 to 7

Above chart for planters equipped with 7.60-15 inch drive tires and 1:1 drive sprocket ratios. Recommended tire pressure 40 PSI.

**IMPORTANT: Soybean rates may vary widely depending upon size of the seed.**

**If lower rates are desired, special drive sprockets are available on a special order basis.**

**IMPORTANT: To prevent planting miscalculations, make field checks to be sure you are planting at the desired rate.**

# OPERATION

## PLANTING RATE FOR PLATELESS REGULAR RATE SORGHUM METERS

Approximate Pounds Per Acre		Sprocket Combinations		Recommended Speed Range In MPH
30 Inch Rows	36 Inch To 40 Inch Rows	Drive Sprocket	Driven Sprocket	
21.0	16.7	30	14	2 to 3
17.5	13.9	26	14	2 to 3½
16.2	12.9	30	18	3 to 4
15.1	12.0	22	14	3 to 4½
13.8	10.9	26	18	3 to 4½
12.9	10.2	30	22	3 to 5
11.8	9.4	22	18	3 to 5½
11.2	8.9	26	22	3 to 6
11.1	8.8	30	26	3 to 6
10.9	8.6	16	14	3 to 6
10.0	7.9	30	28	4 to 6½
9.6	7.6	22	22	4 to 7
9.1	7.2	26	28	4 to 7½
8.8	7.0	16	18	4 to 8
8.5	6.7	22	26	4 to 8
8.0	6.3	22	28	4 to 8
7.9	6.3	14	18	4 to 8
7.6	6.0	16	22	4 to 8
7.0	5.6	14	22	4 to 8
6.8	5.4	16	26	4 to 8
6.3	5.0	16	28	4 to 8
6.2	4.9	14	26	4 to 8
5.9	4.7	14	28	4 to 8

Above chart for planters equipped with 7:60-15 inch drive tires and 1:1 drive sprocket ratio. Recommended tire pressure 40 PSI.

**IMPORTANT:** To prevent planting miscalculations, make field checks to be sure you are planting at the desired rate.

# OPERATION

## PLANTING RATE FOR PLATELESS LOW RATE SORGHUM METERS

Approximate Pounds Per Acre		Sprocket Combinations		Recommended Speed Range In MPH
30 Inch Rows	36 Inch to 40 Inch Rows	Drive Sprocket	Driven Sprocket	
6.2	4.9	30	14	2 to 3
5.4	4.3	26	14	2 to 3½
4.8	3.8	30	18	3 to 4
4.6	3.6	22	14	3 to 4½
4.2	3.3	26	18	3 to 4½
4.0	3.1	30	22	3 to 5
3.6	2.8	22	18	3 to 5½
3.4	2.7	26	22	3 to 6
3.4	2.7	30	26	3 to 6
3.3	2.6	16	14	3 to 6
3.1	2.4	30	28	4 to 6½
2.9	2.3	22	22	4 to 7
2.7	2.1	26	28	4 to 7
2.6	2.1	16	18	4 to 7
2.5	2.0	22	26	4 to 7
2.3	1.8	22	28	4 to 7
2.3	1.8	14	18	4 to 7
2.1	1.7	16	22	4 to 7
1.9	1.5	14	22	4 to 7
1.8	1.4	16	26	4 to 7
1.7	1.3	16	28	4 to 7
1.6	1.2	14	26	4 to 7
1.5	1.2	14	28	4 to 7

Above chart for planters equipped with 7:60-15 inch drive tires and 1:1 drive sprocket ratios. Recommended tire pressure 40 PSI.

**IMPORTANT:** To prevent planting miscalculation, make field checks to be sure you are planting at the desired rate

# OPERATION

## PLANTING RATE FOR PLATE TYPE DRIVE

Seed Population and Drilling Distance - 16 Cell Plate

Seed Populations Per Acre				Average Seed Placement In Inches	Sprocket Combinations		Recommended Speed Range In MPH
30"	36"	38"	40"		Drive Sprocket	Driven Sprocket	
30,500	25,400	24,000	22,900	6-3/4	30	14	2 to 3
26,400	22,000	20,900	19,800	8	26	14	2 to 3-1/2
23,700	19,700	18,700	17,800	8-3/4	30	18	3 to 4
22,400	18,600	17,700	16,800	9-1/4	22	14	3 to 4-1/2
20,600	17,100	16,200	15,400	10-1/4	26	18	3 to 5
19,400	16,100	15,300	14,500	10-3/4	30	22	3 to 5
17,400	14,500	13,700	13,000	12	22	18	3 to 6
16,800	14,000	13,300	12,600	12-1/2	26	22	3 to 6
16,400	13,700	13,000	12,300	12-3/4	30	26	3 to 6
16,300	13,500	12,800	12,200	13	16	14	3 to 6
15,200	12,700	12,000	11,400	13-3/4	30	28	4 to 6-1/2
14,200	11,800	11,200	10,700	14-3/4	22	22	4 to 7
13,200	11,000	10,400	9,900	15-3/4	26	28	4 to 7-1/2
12,600	10,500	10,000	9,500	16-1/2	16	18	4 to 8
12,000	10,000	9,500	9,000	17-1/2	22	26	4 to 8
11,200	9,300	8,800	8,400	18-3/4	22	28	4 to 8
11,000	9,200	8,700	8,300	19	14	18	4 to 8
10,900	9,000	8,200	7,800	20-1/4	16	22	4 to 8
9,000	7,500	7,100	6,800	23	14	22	4 to 8
8,700	7,300	6,900	6,600	24	16	26	4 to 8
8,100	6,800	6,400	6,100	25-3/4	16	28	4 to 8
7,700	6,400	6,000	5,700	27-1/4	14	26	4 to 8
7,100	5,900	5,600	5,300	29-1/2	14	28	4 to 8

*For 32-inch rows, multiply plant population per acre in 30-inch row spacing column by 0.9375.*

*For 34-inch rows, multiply plant population per acre in 30-inch row spacing column by 0.8824.*

*For 32 cell seed plate, multiply population by 2; divide drilling distance by 2.*

*For 48 cell seed plate, multiply population by 3; divide drilling distance by 3.*

*For 64 cell seed plate, multiply population by 4; divide drilling distance by 4.*

Above chart for planters equipped with 7.60-15 inch drive tires and 1:1 drive sprocket ratios. Recommended tire pressure 40 PSI.

**IMPORTANT: The above sprocket combinations are best for average conditions. Changes in sprocket combinations may be required to obtain desired planting population.**

The size and shape of seeds will effect the planting rate. Medium round corn is generally the most preferred while small flat is the least desirable. Higher than optimum speeds may result in population rate increases or higher incidents of doubles and triples, particularly with the small flat seeds.

**IMPORTANT: To prevent planting miscalculations, make field checks to be sure you are planting at the desired rate.**

# OPERATION

## PLANTING RATE FOR PLATE TYPE DRIVE

Seed Population and Drilling Distance - 24 Cell Plate

Seed Populations Per Acre				Average Seed Placement In Inches	Sprocket Combinations		Recommended Speed Range In MPH
30"	36"	38"	40"		Drive Sprocket	Driven Sprocket	
45,700	38,100	36,100	34,300	4-1/2	30	14	2 to 3
39,700	33,100	31,300	29,800	5-1/4	26	14	2 to 3-1/2
35,500	29,600	28,000	26,600	6	30	18	3 to 4
33,500	27,900	26,500	25,100	6-1/4	22	14	3 to 4-1/2
30,800	25,700	24,300	23,100	6-3/4	26	18	3 to 5
29,100	24,300	23,000	21,800	7-1/4	30	22	3 to 5
26,100	21,800	20,600	19,600	8	22	18	3 to 6
25,200	21,000	19,900	18,900	8-1/4	26	22	3 to 6
24,600	20,500	19,400	18,400	8-1/2	30	26	3 to 6
24,400	20,300	19,300	18,300	8-1/2	16	14	3 to 6
22,900	19,100	18,100	17,200	9-1/4	30	28	4 to 6-1/2
21,300	17,800	16,800	16,000	9-3/4	22	22	4 to 7
19,800	16,500	15,600	14,900	10-1/2	26	28	4 to 7-1/2
19,000	15,800	15,000	14,200	11	16	18	4 to 8
18,000	15,000	14,200	13,500	11-1/2	22	26	4 to 8
16,800	14,000	13,200	12,600	12-1/2	22	28	4 to 8
16,600	13,800	13,100	12,400	12-1/2	14	18	4 to 8
15,500	12,900	12,300	11,600	13-1/2	16	22	4 to 8
13,600	11,300	10,700	10,200	15-1/2	14	22	4 to 8
13,100	10,900	10,300	9,800	16	16	26	4 to 8
12,200	10,100	9,600	9,100	17-1/4	16	28	4 to 8
11,500	9,600	9,100	8,600	18-1/4	14	26	4 to 8
10,700	8,900	8,400	8,000	19-1/2	14	28	4 to 8

For 12 cell seed plate, divide population by 2; multiply drilling distance by 2.  
 For 36 cell seed plate, multiply population by 1.5; divide drilling distance by 1.5

Above chart for planters equipped with 7.60-15 inch drive tires and 1:1 drive sprocket ratios.  
 Recommended tire pressure 40 PSI.

**IMPORTANT: The above sprocket combinations are best for average conditions. Changes in sprocket combinations may be required to obtain desired planting populations.**

The size and shape of seeds will effect the planting rate. Medium round corn is generally the most preferred while small flat is the least desirable. Higher than optimum speeds may result in population rate increases or higher incidents of doubles and triples, particularly with the small flat seeds.

**IMPORTANT: To prevent planting miscalculations, make field checks to be sure you are planting at the desired rate.**

# OPERATION

## DRY INSECTICIDE APPLICATION RATES

Clay Granules Approximate Rate In Pounds Per Acre At 5 MPH			
Meter Setting	30 Inch Rows	36 Inch Rows	38 Inch Rows
10	4.1	3.4	3.3
12	5.4	4.5	4.3
14	6.8	5.7	5.4
16	8.1	6.8	6.5
18	9.4	7.9	7.5
20	10.7	9.0	8.5
22	12.1	10.1	9.6
24	13.4	11.2	10.6
26	14.7	12.3	11.6
28	16.1	13.4	12.7
30	18.1	15.1	14.3
32	20.1	16.8	15.8
34	22.7	19.0	18.0
36	25.4	21.2	20.1
Sand Granules Approximate Rate In Pounds Per Acre At 5 MPH			
Meter Setting	30 Inch Rows	36 Inch Rows	38 Inch Rows
6	4.8	4.0	3.8
8	6.8	5.7	5.4
10	8.6	7.2	6.8
12	10.5	8.7	8.3
14	12.1	10.1	9.6
16	13.7	11.4	10.8
18	16.1	13.4	12.7
20	18.5	15.4	14.6
22	21.4	17.9	16.9
24	24.1	20.1	19.1
26	28.1	23.4	22.2

Variations in pounds per acre may occur with changes in seed planting rates.

Rate is affected by changes in temperature and climatic conditions. Changes in speed or field conditions may also affect metering rates.

**IMPORTANT:** To prevent application miscalculations, make field checks to be sure you are applying at the desired rate.

# OPERATION

---

## DRY HERBICIDE APPLICATION RATES

Clay Granules Approximate Rate In Pounds Per Acre At 5 MPH			
Meter Setting	30 Inch Rows	36 Inch Rows	38 Inch Rows
6	4.1	3.4	3.3
8	5.4	4.5	4.3
10	6.7	5.6	5.3
12	8.1	6.7	6.4
14	9.4	7.9	7.5
16	10.7	8.1	8.6
18	12.1	10.1	9.6
20	13.4	11.2	10.6
22	14.4	12.3	11.7
24	16.1	14.5	12.7
26	18.7	15.6	14.8
28	20.4	17.1	16.2
30	23.4	19.5	18.5

Variations in pounds per acre may occur with changes in seed planting rates.

Rate is affected by changes in temperature and climatic conditions. Changes in speed or field conditions may also affect metering rates.

**IMPORTANT: To prevent application miscalculations, make field checks to be sure you are applying at the desired rate.**

# MAINTENANCE

## Mounting Bolts and Hardware

Before operating the planter for the first time, check to be sure all nuts and bolts are tight. Check all nuts and bolts again after approximately the first 50 hours of operation and at the beginning of each planting season thereafter.

All bolts used on the Kinze planter are Grade 5 (high strength) unless otherwise noted. Refer to the torque value chart in the Assembly Section of this manual when tightening bolts.

**NOTE: Overtightening bolts can cause as much damage as undertightening. Tightening a bolt beyond the recommended range can reduce its shock load capacity.**

## Chain Tension Adjustment


Drive chains from the drive gauge wheels to the clutch assembly are equipped with spring tensioned idlers to minimize chain adjustment.

To increase chain tension on transmission idler, loosen mounting nut and rotate idler to desired tension and retighten nut.

## Flow Control Valve Inspection

The flow control valves should be adjusted for raise and lower speed as part of the assembly procedure or upon initial operation. If the valve fails to function properly or requires frequent adjustment, the needle valve should be removed for inspection. Check for foreign material and contamination on both the valve and the seating area of the valve body. Replace any components found to be defective.

## Flow Control Valve




## Sequencing Valve Inspection

The sequencing valve consists of a chambered body containing a spool and a series of check valves to direct hydraulic flow. Should the valve malfunction, the components may be removed for inspection. The spool is accessible by removing either side plug and one check valve is accessible from the top of the valve body. It is necessary to disconnect the outlet hoses from the back of the valve to gain access to the remaining retainers and check valves. Inspect all parts for pitting, contamination or foreign material. Also check seating surfaces inside the valve. Replace any parts found to be defective.

**IMPORTANT: Make sure correct check ball and spring are installed in each check valve bore upon reassembly.**

## Sequencing Valve





# MAINTENANCE

---

## Wheel or Marker Bearing Lubrication or Replacement

1. Raise tire clear of ground and remove wheel or marker disk.
2. Remove hub cap from hub.
3. Remove cotter pin, axle nut, and washer.
4. Slide hub from axle or spindle.
5. Remove bearing cups and discard if bearings are being replaced. Clean hub and dry.
6. Press in new bearing cups with thickest edge facing in.
7. Pack bearings with heavy duty wheel bearing grease thoroughly forcing grease between roller cone and bearing cage. Also fill the space between the bearing cups in the hub with grease.
8. Place inner bearing in place and press in new grease seal.
9. Clean axle or spindle and install hub.
10. Install outer bearing, washer, or outer seal and slotted hex nut. Tighten slotted hex nut while rotating hub until there is some drag. This assures that all bearing surfaces are in contact. Back off slotted nut to nearest locking slot and install cotter pin.
11. Fill hub caps approximately 3/4 full of wheel bearing grease and install on hub.
12. Install wheel or disk on hub and tighten evenly and securely.

## Storage

Store the planter in a dry sheltered area if possible.

Remove all trash that may be wrapped on sprockets or shafts and remove dirt that can draw and hold moisture.

Clean all drive chains and coat with a rust preventative spray, or better yet, remove chains and submerge in oil.


Lubricate planter and row units at all lubrication points.

If possible, remove weight from all tires particularly if the unit is stored outdoors, in which case it is best to remove wheels and tires for storage in a cool dry area.

Inspect the planter and row units for parts that are in need of replacement and order during the "off" season.

Make sure all seed, herbicide and insecticide hoppers are empty and clean.

Clean plateless seed meters and store in a dry area.




# PARTS LIST INDEX

---


Planter Frame .....	21
Drive Gauge Bracket Assembly .....	22-23
Drive Gauge Wheel Assembly .....	24
Decals and Reflectors .....	25
Transmission Assembly .....	26-27
Marker Hub Assembly .....	28
Conventional Marker Assembly .....	29
Low Profile Double Fold Marker Assembly .....	30-31
Sequencing Valve and Flow Control Valve .....	32
Hydraulic System, Dual Valve, 4R30, 4RW and 6R30 .....	33
Hydraulic System, Single Valve, 4R30, 4RW and 6R30 .....	34
Hydraulic System, Dual Valve, 6RW and 8R30 .....	35
Hydraulic System, Single Valve, 6RW and 8R30 .....	36
Low Profile Double Fold Marker Cylinder .....	37
Conventional Marker Cylinder .....	38-39

# PLANTER FRAME



ITEM	PART NO.	DESCRIPTION
1.	A727 A669 A670 A671 A923 A924	Frame, 90", 2R30 and 2R Wide Frame, 128", 4R30 Frame, 136", 4R Wide Frame, 169", 6R30 Frame, 214", 6R Wide Frame, 229", 8R30
2.	A1816	Transmission Assembly
3.	A1915	Bracket, Drive Gauge
4.	D503	Clamp
5.	D2637 D978	Plate, Valve, L.H. Plate, Valve, R.H. (Shown)
6.	10037	HHCS, 1/2" - 13 x 1 1/4"
7.	10228	Lock Washer, 1/2"
8.	10102	Hex Nut, 1/2" - 13
9.	10670	Clip No. 3
10.	D2557	Pin, Lynch, 7/16"
11.	A1818	Pin, Center Link
12.	D1114	U-Bolt, 5/8" - 11 x 7" x 7"
13.	10230	Lock Washer, 5/8"
14.	10104	Hex Nut, 5/8" - 11
15.	A667	Bracket, Support Stand
16.	10561	Clevis Pin, 1/2" x 3"
17.	A668	Stand
18.	A1817	Pin, Lower Link
19.	10027	HHCS, 3/4" - 10 x 2 1/2"
20.	10231	Lock Washer, 3/4"
21.	10105	Hex Nut, 3/4" - 10

# DRIVE GAUGE BRACKET ASSEMBLY




# DRIVE GAUGE BRACKET ASSEMBLY

---

ITEM	PART NO.	DESCRIPTION
1.	A271	Lock Collar, Hex Bore
2.	D1256	Spring
3.	10464	Cotter Pin, 3/16" x 1"
4.	A378	Block and Hub Assembly
5.	D1255	"L" Pin
6.	A376	Hub/Sprocket Assembly
7.	10430	Ring, Retaining, 1 1/4"
8.	A849	Sprocket, 48T, Extended Drill
9.	10229	Lock Washer, 3/8"
10.	10002	HHCS, 3/8" - 16 x 3/4"
11.	A1915	Bracket, Drive Gauge
12.	10233	Bushing, Machinery
13.	3400-1	Flangette
14.	2100-3	Bearing, 7/8" Hex
15.	10466	Cotter Pin, 1/4" x 3/4"
16.	D913	Spring
17.	A272	Arm, Idler
18.	10670	Hairpin Clip, No. 3
19.	10435	Ring, Snap
20.	D916	Spool
21.	A182	Bracket, Idler
	A852	Bracket, Idler, For Use With Extended Drill Sprocket
22.	D914-30	Drive Shaft, 7/8" Hex, L.H., 2R30 and 4R30
	D914-35	Drive Shaft, 7/8" Hex, R.H., 2R30 and 4R30
	D914-35	Drive Shaft, 7/8" Hex, L.H., 2RW and 4RW
	D914-45	Drive Shaft, 7/8" Hex, R.H., 2RW and 4RW
	D914-55	Drive Shaft, 7/8" Hex, L.H., 6R30
	D914-65	Drive Shaft, 7/8" Hex, R.H., 6R30
	D914-75	Drive Shaft, 7/8" Hex, L.H., 6RW
	D914-85	Drive Shaft, 7/8" Hex, R.H., 6RW
	D914-85	Drive Shaft, 7/8" Hex, L.H., 8R30
	D914-95	Drive Shaft, 7/8" Hex, R.H., 8R30
23.	10303	Carriage Bolt, 5/16" - 18 x 1"
24.	10106	Hex Nut, 5/16" - 18
25.	10232	Lock Washer, 5/16"
26.	10009	HHCS 5/8" - 11 x 2 1/2" For use with extended drill sprocket
27.	A262	Sprocket, Idler, 15T, For use with extended drill sprocket
28.	B123	Bushing, For use with extended drill sprocket
29.	10205	Washer, 5/8" SAE, For use with extended drill sprocket
30.	10107	Lock Nut, 5/8" - 11, For use with extended drill sprocket
A.	A261L	Ratchet and Sprocket Assembly, L.H. (Items 2 thru 7)
B.	R444	Idler Assembly (Items 15 thru 21)
C.	R4004	Extended Drill Sprocket Package Includes: (2) A849 (2) A852 (2) 3200-6 (8) 10002 (8) 10229 (2) A262 (2) 10009 (2) B123 (4) 10205 (2) 10107


# DRIVE GAUGE WHEEL ASSEMBLY



## ITEM PART NO. DESCRIPTION

1.	10026	HHCS, 3/4" - 10 x 2"
2.	10231	Lock Washer, 3/4"
3.	A652	Spindle Weld
4.	A252	Seal, Grease
5.	A251	Bearing
6.	R190	Cup
7.	R267	Nut, Wheel, 1/2" - 20 UNF
8.	A547	Hub, w/Cups and Studs
9.	R204	Stud, Wheel, 1/2" - 20 UNF x 1 7/8"
10.	3200-58	Chain, NO. 2050, 58 Pitch Including Connector Link
	3200-6	Chain, No. 2050 (Add to chain when using extended drill sprocket)
	R195	Connector Link, No. 2050
11.	2500-17	Sprocket, Bolt-on, 12 Tooth
12.	10232	Lock Washer, 5/16"
13.	10019	HHCS, 5/16" - 18 x 1"
14.	D831	Nut, Shoulder, 1 1/4"
15.	D1166	Valve Stem
16.	A241	Wheel, 15" x 5", 5 bolt
17.	D844	Tire, 7.60 x 15", 4 ply
A.	A683	Drive Hub Assembly (Items 1-9 and 11-14)
B.	A374	Tire and Rim Assembly, 7.60 x 15" (Item 15-17)


# DECALS AND REFLECTORS



1




2



3



4




5

ITEM	PART NO.	DESCRIPTION
1.	7100-4	Decal, Caution-Markers
2.	7100-14	Decal, Kinze
3.	7100-6	Decal, Sprocket Combination - Seed Drive Transmission.
4.	D937	Serial Number Plate
5.	7200-1	Reflector, Red (Used on Rear of Planter Box)
	7200-2	Reflector, Amber (Used on Front of Toolbar)

# TRANSMISSION ASSEMBLY

---






# TRANSMISSION ASSEMBLY

---


ITEM	PART NO.	DESCRIPTION
1.	A177	Case, Transmission
2.	D832	Spacer, Rubber
3.	2500-3	Sprocket, 16-30T
4.	2500-1	Sprocket, 14T
5.	2500-2	Sprocket, 22-26T
6.	3300-40	Chain, No. 2040, 40 Pitch Including Connector Link
	R194	Connector Link, No. 2040
7.	2500-6	Sprocket, 18-28T
8.	D925	Shaft, Upper
9.	D926	Shaft, Lower
10.	D2495	Angle, Idler Lock
11.	10463	Cotter Pin, 1/4" x 1 1/2"
12.	3400-1	Flangette
13.	2100-3	Bearing, 7/8" Hex Bore
14.	10301	Carriage Bolt, 3/8" - 16 x 1 1/2"
15.	10670	Hair Pin Clip, No. 3
16.	10640	Fitting, Grease, 1/4"
17.	10303	Carriage Bolt, 5/16" - 18 x 1"
18.	10232	Lock Washer, 5/16"
19.	10106	Hex Nut, 5/16" - 18
20.	10435	Ring, Retaining
21.	D1067	Spool
22.	A242	Bracket, Idler
23.	D747	Coupler, 9/16"
24.	D748	Coupler, 7/8"
25.	10455	Cotter Pin, 1/16" x 1/2"
26.	10462	Cotter Pin, 3/16" x 2"
27.	10548	Clevis Pin, 1/4" x 1 3/4"
28.	D1114	U-Bolt, 5/8" - 11 x 7" x 7"
29.	10230	Lock Washer, 5/8"
30.	10104	Hex Nut, 5/8" - 11
31.	10558	Clevis Pin, 5/16" x 1 3/4"
32.	D1649	Coupler
33.	10456	Cotter Pin, 1/8" x 3/4"
34.	A1668	Lock, Idler
35.	10210	Flat Washer, 3/8"
36.	10101	Hex Nut, 3/8" - 16
37.	D739-25	Drill Shaft, 9/16" Hex, L.H., 2R30
	D739-30	Drill Shaft, 9/16" Hex, L.H., 2RW
	D739-50	Drill Shaft, 9/16" Hex, L.H., 4R30
	D739-60	Drill Shaft, 9/16" Hex, L.H., 4RW
	D739-80	Drill Shaft, 9/16" Hex, L.H., 6R30
	D739-100	Drill Shaft, 9/16" Hex, L.H., 6RW
	D739-110	Drill Shaft, 9/16" Hex, L.H., 8R30
38.	D739-15	Drill Shaft, 9/16" Hex, R.H., 2R30
	D739-20	Drill Shaft, 9/16" Hex, R.H., 2RW
	D739-40	Drill Shaft, 9/16" Hex, R.H., 4R30
	D739-50	Drill Shaft, 9/16" Hex, R.H., 4RW
	D739-70	Drill Shaft, 9/16" Hex, R.H., 6R30
	D739-90	Drill Shaft, 9/16" Hex, R.H., 6RW
	D739-100	Drill Shaft, 9/16" Hex, R.H., 8R30
A.	A503	Idler Assembly (Items 20 thru 22)
B.	A1816	Transmission Assembly (Items 1 thru 27 and 34 thru 36)

# MARKER HUB ASSEMBLY




ITEM	PART NO.	DESCRIPTION
1.	D840	Hub Cap
2.	10725	Hex Nut, Slotted, 5/8" - 18
3.	10470	Cotter Pin, 5/32" x 1"
4.	10724	Washer, 5/8"
5.	A257	Bearing, Outer
6.	10722	HHCS, 1/2" - 20 x 1"
7.	R151	Cup, Outer
8.	10228	Lockwasher, 1/2"
9.	A167	Hub w/cups
10.	R150	Cup, Inner
11.	A245	Bearing Inner
12.	A899	Seal, Rubber
13.	A243	Seal, Grease
14.	A1677	Spindle Weld, L.H., Less Hardware (Shown)
	A1676	Spindle Weld, R.H. Less Hardware
15.	10102	Hex Nut, 1/2" - 13
16.	10168	Machinery Bushing, 1/2" x 7 Ga.
17.	10033	HHCS, 1/2" - 13 x 3 1/2"
18.	D2597	Retainer
A.	A1679	Hub and Spindle Assembly L.H. (Items 1-14)
	A1678	Hub and Spindle Assembly R.H. (Items 1-14)

# CONVENTIONAL MARKER ASSEMBLY



ITEM	PART NO.	DESCRIPTION
1.	10167	HHCS, 1/2" - 13 x 2", Grade 2
2.	10228	Lockwasher, 1/2"
3.	10102	Hex Nut, 1/2" - 13
4.	A224	Marker Mount
5.	10609	Roll Pin, 5/32" x 1"
6.	10670	Hair Pin Clip, No. 3
7.	D462	Marker Lockup Pin
8.	10460	Cotter Pin, 1/4" x 2"
9.	D438	Shaft
10.	A225	Marker Arm Weld, 45", 4R30 and 4RW
	A538	Marker Arm Weld, 64", 6R30
11.	10640	Grease Fitting, 1/4" - 28
12.	A1674A	Cylinder Assembly, 2 x 8
	A1674B	Cylinder Assembly, 2 x 8
13.	10033	HHCS, 1/2" - 13 x 3 1/2"
14.	D453-1	Extension Tube, 20", 4R30
	D453-2	Extension Tube, 40", 6R30
	D453-3	Extension Tube, 50", 4RW
15.	A1679	Marker Hub Assembly, L.H. (Less Hardware)
	A1678	Marker Hub Assembly, R.H. (Less Hardware)
16.	D746	Disc., 16"
17.	10722	HHCS, 1/2" - 20 x 1"

# LOW PROFILE - DOUBLE FOLD MARKER ASSEMBLY




# LOW PROFILE - DOUBLE FOLD MARKER ASSEMBLY

---


ITEM	PART NO.	DESCRIPTION
1.	D453-3	Extension Tube, 50", 8R30
	D453-5	Extension Tube, 55", 6RW
2.	10033	HHCS, 1/2" - 13 x 3 1/2"
3.	10228	Lockwasher, 1/2"
4.	10102	Hex Nut, 1/2" - 13
5.	A831	Marker Arm, 34", 6RW
	A832	Marker Arm, 45", 8R30
6.	10460	Cotter Pin, 1/4" x 2"
7.	D1702	Pivot Pin
8.	D1701	Pin
9.	10226	Washer, 1 1/4" SAE
10.	10641	Grease Fitting, 1/8" NPT
11.	A828	Arm, First Stage
12.	A827	Marker Mount
13.	10167	HHCS, 1/2" - 13 x 2", Grade 2
14.	2501-8-8	Elbow, 90°, 1/2" NPT to 3/4" - 16 JIC
15.	A1659	Cylinder, 2" x 20"
16.	D653	Pin

# SEQUENCING VALVE




ITEM	PART NO.	DESCRIPTION
1.	R272	Valve Body and Spool
2.	R271	Plug Assembly, O-Ring Boss
3.	R273	Retainer, Check Valve
4.	R277	Spring, Check Valve
5.	R275	Ball, Check, 3/16" Diameter
6.	R274	Plug Assembly, O-Ring Boss
7.	R278	Spring
8.	R276	Ball, 1/4" Diameter
A.	A282	Sequencing Valve, Complete

# FLOW CONTROL VALVE




ITEM	PART NO.	DESCRIPTION
1.	A270	Flow Control Valve Assembly, 3/8" NPT (KLF 375)

## DUAL VALVE SYSTEM CONVENTIONAL MARKER



ITEM	PART NO.	DESCRIPTION
1.	A1674A	Cylinder, Marker, 2" x 8"
	A1674B	Cylinder, Marker, 2" x 8"
2.	2501-6-6	Elbow, 90°
3.	A1102	Hose Assembly, 1/4" x 95", 4R30 and 4 RW
	A1103	Hose Assembly, 1/4" x 110", 6R30
4.	2501-6-6	Elbow, 90°
5.	A270	Valve, Flow Control
6.	2404-6-6	Adapter, Straight
7.	A1101	Hose Assembly, 1/4" x 48"
8.	D1253	U-Bolt, 5/16" - 18 x 2 1/4" x 1 1/2"
9.	10219	Flat Washer, 5/16"
10.	10232	Lock Washer, 5/16"
11.	10106	Hex Nut, 5/16" - 18
	D1512	Tie Strap, 6" (Not Shown)


## SINGLE VALVE CONVENTIONAL MARKER



ITEM	PART NO.	DESCRIPTION
1.	A1674A	Cylinder, Marker, 2" x 8"
	A1674B	Cylinder, Marker 2" x 8"
2.	2501-6-6	Elbow, 90°
3.	A1102	Hose Assembly, 1/4" x 95", 4R30, 4RW
	A1103	Hose Assembly, 1/4" x 110", 6R30
4.	6801-6-8	Elbow, 90°
5.	A282	Valve, Seq.
6.	6401-8-6	Adapter Straight
7.	2601-6-6	Side Tee, Male
8.	A270	Valve, Flow Control
9.	2404-6-6	Adapter, Straight
10.	A1101	Hose Assembly, 1/4" x 48"
11.	10048	HHCS, 3/8" - 16 x 2"
12.	10229	Lock Washer, 3/8"
13.	10101	Hex Nut, 3/8" - 16
14.	D1253	U-Bolt, 5/16" - 18 x 2 1/4" x 1 1/2"
15.	10219	Flat Washer, 5/16"
16.	10232	Lock Washer, 5/16"
17.	10106	Hex Nut, 5/16" - 18
	D1512	Tie Strap, 6" (Not Shown)




## DUAL VALVE LOW PROFILE DOUBLE FOLDING MARKER




ITEM	PART NO.	DESCRIPTION
1.	A1659	Cylinder, Marker, 2" x 20"
2.	2501-8-8	Elbow, 90°
3.	A1008	Hose Assembly, 3/8" x 110", 6RW
	A1010	Hose Assembly, 3/8" x 120", 8R30
4.	A1004	Hose Assembly, 3/8" x 36"
5.	2501-8-6	Elbow, 90°
6.	A270	Valve, Flow Control
7.	2404-8-6	Adapter, Straight
8.	A1005	Hose Assembly, 3/8" x 48"
9.	D1253	U-Bolt, 5/16" - 18 x 2 1/4" x 1 1/2"
10.	10219	Flat Washer, 5/16"
11.	10232	Lock Washer, 5/16"
12.	10106	Hex Nut, 5/16" - 18
	D1512	Tie Straps, 6" (Not Shown)

## SINGLE VALVE LOW PROFILE DOUBLE FOLDING MARKER




ITEM	PART NO.	DESCRIPTION
1.	A1659	Cylinder, Marker, 2" x 20"
2.	2501-8-8	Elbow, 90°
3.	A1008	Hose Assembly, 3/8" x 110", 6RW
	A1010	Hose Assembly, 3/8" x 120", 8R30
4.	A1004	Hose Assembly, 3/8" x 36"
5.	6801-8	Elbow, 90°
6.	A282	Valve, Seq.
7.	6401-8-6	Adapter, Straight
8.	2601-8-6	Side Tee, Male
9.	A270	Valve, Flow Control
10.	2404-8-6	Adapter, Straight
11.	A1005	Hose Assembly, 3/8" x 48"
12.	10048	HHCS, 3/8" - 16 x 2"
13.	10229	Lock Washer, 3/8"
14.	10101	Hex Nut, 3/8" - 16
15.	D1253	U-Bolt, 5/16" - 18 x 2 1/4" x 1 1/2"
16.	10219	Flat Washer, 5/16"
17.	10232	Lock Washer, 5/16"
18.	10106	Hex Nut, 5/16" - 18
	D1512	Tie Strap, 6" (Not Shown)

# LOW PROFILE DOUBLE FOLDING MARKER CYLINDER



ITEM	PART NO.	DESCRIPTION
1.	R553	Tube Assembly
2.	R366	Nut, 3/4" - 16 NF
3.	R365	Piston
4.	R552	Head Gland
5.	R551	Shaft Assembly
A.	A1659 R368	Cylinder Assembly, Complete 2" x 20" Seal Kit Includes: (1) O-Ring, 614 I.D. x .754 O.D. (1) O-Ring, 1.109 I.D. x 1.387 O.D. (2) O-Ring, 1.600 I.D. x 2.200 O.D. (1) Back Up Washer, 1 1/8" I.D. x 1 3/8" O.D. (1) Rod Wiper 2" I.D. (1) Retaining Ring Internal 2" (2) Back Up Washer 1 5/8" I.D. x 2" O.D.

# CONVENTIONAL MARKER CYLINDER




ITEM	PART NO.	DESCRIPTION
------	----------	-------------

- |    |      |  |
|----|------|--|
| 1. | R366 | Hex Nut, 3/4" NF                             |
| 2. | R365 | Piston                                       |
| 3. | R362 | Tube Assembly                                |
| 4. | R364 | Head Gland                                   |
| 5. | R363 | Shaft Assembly                               |
| 6. | R367 | Clevis Pin                                   |
| 7. | R193 | Clip, Hair Pin Only                          |
|    | R368 | Seal Kit Includes                            |
|    |      | (1) O-Ring .614 I.D. x .754 O.D.             |
|    |      | (1) O-Ring 1.109 I.D. x 1.387 O.D.           |
|    |      | (2) O-Ring 1.600 I.D. x 2.200 O.D.           |
|    |      | (1) Back Up Washer 1 1/8" I.D. x 1 3/8" O.D. |
|    |      | (1) Rod Wiper 2" I.D.                        |
|    |      | (1) Retaining Ring Internal 2"               |
|    |      | (2) Back Up Washer 1 5/8" O.D. x 2 O.D.      |

\*A. A1674A Cylinder, Complete, 2" x 8", Style No. 1

\* To identify - Super Draulic Stamped on Barrel

# CONVENTIONAL MARKER CYLINDER



ITEM	PART NO.	DESCRIPTION
1.	R157	Cylinder Body
2.	R158	Piston Rod
3.	R159	Hex Nut, 7/8" UNF
4.	R160	Piston
5.	R161	Piston Rod Guide
6.	R162	Clevis Pin w/Clip
7.	R193	Clip, Hair Pin, Only
	R154	Seal Kit Includes
		(1) O-Ring, 3/4" I.D. x 7/8" O.D.
		(1) O-Ring, 1 1/8" I.D. x 1 3/8" O.D.
		(1) Back Up Washer
		(1) Rod Wiper
		(2) Back Up Washer
		(2) O-Ring, 1 5/8" I.D. x 2" O.D.
		(1) Retaining Ring
*A.	A1674B	Cylinder - Complete 2" x 8", Style No. 2

\* To identify - No marking on barrel

# NUMERICAL INDEX

<b>A</b>		<b>D</b>		<b>R</b>			
PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE
A167	28	D438	29	R150	28	2100-3	23, 27
A177	27	D453-1	29	R151	28	2404-6-6	33, 34
A182	23	D453-2	29	R154	39	2404-8-6	35, 36
A224	29	D453-3	29, 31	R157	39	2500-1	27
A225	29	D453-5	31	R158	39	2500-2	27
A241	24	D462	29	R159	39	2500-3	27
A242	27	D503	21	R160	39	2500-6	27
A243	28	D653	31	R161	39	2500-17	24
A245	28	D739-15	27	R162	39	2501-6-6	33, 34
A251	24	D739-20	27	R190	24	2501-8-6	35
A252	24	D739-25	27	R193	38, 39	2501-8-8	31, 35, 36
A257	28	D739-30	27	R194	27		
A261L	23	D739-40	27	R195	24	2601-6-6	34
A262	23	D739-50	27	R204	24	2601-8-6	36
A270	32, 33, 34, 35, 36	D739-60	27	R267	24	3200-6	24
A271	23	D739-70	27	R271	32	3200-58	24
A272	23	D739-80	27	R273	32	3300-40	27
A282	32, 34, 36	D739-90	27	R274	32	3400-1	23, 27
A374	24	D739-100	27	R275	32	6401-8-6	34, 36
A376	23	D739-110	27	R276	32	6801-6-8	34
A378	23	D746	29	R277	32	6801-8	36
A503	27	D747	27	R278	32	7100-4	25
A538	29	D748	27	R362	38	7100-6	25
A547	24	D831	24	R363	38	7100-14	25
A652	24	D832	27	R364	38	7200-1	25
A667	21	D840	28	R365	37, 38	7200-2	25
A668	21	D844	24	R366	37, 38	10002	23
A669	21	D913	23	R367	38	10009	23
A670	21	D914-30	23	R368	37, 38	10019	24
A671	21	D914-35	23	R444	23	10026	24
A683	24	D914-45	23	R551	37	10027	21
A727	21	D914-55	23	R552	37	10033	28, 29, 31
A827	31	D914-65	23	R553	37	10037	21
A828	31	D914-75	23	R4004	23	10048	34, 36
A831	31	D914-85	23			10101	27, 34, 36
A832	31	D914-95	23			10102	21, 28, 29, 31
A849	23	D916	23			10104	21, 27
A852	23	D925	27			10105	21
A899	28	D926	27			10106	23, 27, 33, 34, 35, 36
A923	21	D937	25			10107	23
A924	21	D978	21			10167	29, 31
A1004	35, 36	D1067	27			10168	28
A1005	35, 36	D1114	21, 27			10205	23
A1008	35, 36	D1166	24			10210	27
A1010	35, 36	D1253	33, 34, 35, 36			10219	33, 34, 35, 36
A1101	33, 34	D1255	32			10226	31
A1102	33, 34	D1256	32			10228	21, 28, 29, 31
A1103	33, 34	D1512	33, 34, 35, 36			10229	23, 34, 36
A1659	31, 35, 36, 37	D1649	27			10230	21, 27
A1668	27	D1701	31			10231	21, 24
A1674A	29, 33, 34, 38	D1702	31			10232	23, 24, 27, 33, 34, 35, 36
A1674B	29, 33, 34, 39	D2495	27			10233	23
A1676	28	D2557	21			10301	27
A1677	28	D2597	28			10303	23, 27
A1678	28, 29	D2637	21			10430	23
A1679	28, 29					10435	23, 27
A1816	21, 27					10455	27
A1817	21					10456	27
A1818	21					10460	29, 31
A1915	21, 23					10462	27
						10463	27
						10464	23
						10466	23
						10470	28
						10548	27
						10558	27
						10561	21
						10609	29
						10640	27, 29
						10641	31
						10670	21, 23, 27, 29
						10722	28, 29
						10724	28
						10725	28

## B

B123 .....23