

---

**Heavy Duty Cargo Door Lock Extension:**

- 1) Align the extension with the holes matching on the same side as those on the Heavy Duty Cargo Door Lock
- 2) Insert the extension with the smaller tube side in first.
- 3) Check to see that the 2 threaded screw holes are aligned inside of the main body holes.
- 4) Insert a non-reversing screw having 2 lock washers in each threaded hole.
- 5) Tighten completely so the head of the screw is below the tube surface.



Thank you for your interest in The Equipment Lock Company products.

We look forward to helping you keep your equipment!