

NOTE:

IT IS IMPORTANT THAT THE CONCAVE WASHERS (E) BE SNUGLY NESTED INTO THE CERAMIC BUSHING (F), BETWEEN NUTS (C & D). HOWEVER, NUT MARKED (D) SHOULD BE FINGER TIGHTENED ONLY IN ORDER TO PREVENT DAMAGE TO BUSHING (F).

TO SECURE RING TERMINAL, HOLD (D) NUT WITH SMALL WRENCH [ENSURING TENSION ON CERAMIC BUSHING DOES NOT CHANGE] AND TIGHTEN (C) NUT AGAINST RING TERMINAL.

COMPONENTS

A = #10-24X1.75 STAINLESS STEEL BOLT (1)

B = #10 SS FLAT WASHER (2)

C, D = 10-24 SS NUT (3)

E = #10 SS CONCAVE WASHER (2)

F = SMALL CERAMIC BUSHING (1)

G = BUSHING RETAINER CLIP (1)

H = #10STUD/12-10AWG HI-TEMP RING TERMINAL (1)

