

OWNERS MANUAL



ATV20 **CONTOUR SPRAYER**

INCLUDED IN THIS MANUAL:
Parts List | Setup Instructions | Operating Instructions

F/S **Manufacturing**
Quality Sprayers & Liquid Handling Equipment


www.fsmfg.com

1-800-333-2314

Your ATV20 Should Contain:

Parts Included:

- a. ATV20 Valve Assembly
- b. 60 PSI Gauge
- c. 4' x 1/2" EPDM Hose
- d. (1) Left Riser Bracket
(1) Right Riser Bracket
- e. (4) 5/16" x 3/4" Flange Bolts
- f. (4) 1/4" x 1" Hex Bolts
- g. (4) 1/4" Flat Washers
- h. (4) 1/4" Lock Washers
- i. (4) 1/4" Nuts
- j. (2) #5 Hose Clamp
- k. (1) #10 Hose Clamp
- l. (1) #4 Hose Clamp



Instructions:



1. Bolt the Boom/Boomless mounting riser brackets to the brass inserts on the bottom of the tank using the included 5/16 x 3/4 flange bolts. **(Image 1)**



Image 1

2. Attach the ATV20 valve assembly to the Black Mounting Bracket with included 1/4 hardware. **(Image 2)** Using Teflon Tape or Pipe Dope screw in and attach Gauge to open port on Top of Valve Assembly.



Image 2

3. Connect rubber spray hoses to barbs on bottom of the valve assembly and secure with provided hose clamps. **(Image 3)**



Image 3

4. Securely fasten the assembled contour sprayer to the rack on your ATV using common ratchet straps (Not included) as shown. **(Image 4)**



Image 4

Operation:

As with all spray equipment please Test/Calibrate using only water in the tank before using chemical.

The pump is controlled by the water resistant switch on top of the pump.

Spray pressure is controlled by the Pressure Regulating Valve (horizontal gray knob).

The Boom/Boomless and Wand are individually operated by the two vertical grey control levers

Winterization:

Safely drain all fluid from the tank using the black drain valve located on the bottom side of tank nearest the valve assembly (it may be helpful to tilt tank toward drain/sump on bottom of tank).

Add RV antifreeze (pink) to tank and circulate with pump.

Operate wand until it sprays only antifreeze.

Operate Boom/Boomless until it sprays only antifreeze.

Should you need spare parts or help with your Contour Sprayer please call us and we will do everything possible to help.

Thank you for purchasing a quality product from F/S Manufacturing!

DON'T EVER GIVE UP!



1102 Center Street West Fargo, ND 58078
1-800-333-2314 www.fsmfg.com