



Figure 8. Control cubicle assembly and manual speed control. (sheet 2 of 2) (Landscape)

Current part is item (56) on diagram. Available at www.oshkoshequipment.com

TWS-6115-465-24B
 NAVFAC P-8-625-24P
 SL-4-06858B/06859D

(1) ILLUSTRATION A FIG. NO.	(2) SMR CODE B AIR FORCE	(3) A SSI	(4) NATIONAL STOCK NUMBER	(5) DESCRIPTION REF NUMBER & MFR CODE	(6) USABLE ON CODE U/M	(7) QTY INC IN UNITS	(8) USMC QTY PER EQUIP					
								(2) SMR CODE A ARMY	(3) D USMC	(4) B REPL FACTOR		
8	48	PAOZZ	PAOZZ	PAOZZ	PAOZZ	.230	6240-00-143-3060	LAMP, INCANDESCENT MS15567-1 96906	EA	2	4	
8	49	XBOZZ	PAOZZ	PAOZZ	PAFZZ	D	.020	5355-00-916-2060	KNOB, CONTROL: RHEOSTAT MS91528-2P4B 96906	EA	1	2
8	50	PAOZZ	PAOZZ	PAGZZ	PAFZZ	.090	5905-00-665-7856	RHEOSTAT 69-571-1 30554 M22-04-00181FD 81349	EA	1	1	
8	51	PAOZZ	PAOZZ	PAHZZ	PAFZZ	.050	5390-00-655-1581	SWITCH, TOGGLE: PARALLEL OPERATION MS25068-23 96906	EA	1	2	
8	52	PAOZZ	PAOZZ	PAGZZ	PAFZZ	.050	5930-00-655-1582	SWITCH, TOGGLE: REMOTE CONTROL MS35059-23 96906	EA	1	1	
8	53	PAOZZ	PAOZZ	PAGZZ	PAFZZ	.050	5930-00-655-1514	SWITCH, TOGGLE: PANEL LIGHT MS35058-22 96906	EA	1	1	
8	54	PAOZZ	PAOZZ	PAGZZ	PAFZZ	D	.050	6210-00-688-5088	LIGHT ASSEMBLY: CIRCUIT BREAKER MS25331-4 96906	EA	1	2
8	55	PAOZZ	PAOZZ	PAOZZ	PAOZZ	.040	6240-00-155-8714	LAMP MS25231-313 96906	EA	1	4	
8	56	PAOZZ	PAOZZ	PAHZZ	PAFZZ	.160	5390-00-044-3518	SWITCH, TOGGLE: CIRCUIT BREAKER GLOW MS25201-6 96906	EA	1	1	
8	57	PAOZZ	PAOZZ	PAGZZ	PAFZZ	.050	5930-00-782-8590	SWITCH, TOGGLE: ENGINE START-RUN- STOP 69-572 30554 8906K1359 27192	EA	1	1	
8	58	PAOZZ	PAOZZ	PAGZZ	PAFZZ	.050	5930-00-655-1522	SWITCH, TOGGLE: ENGINE PRIMER MS35058 96906	EA	1	1	
8	59	PAOZZ	PAOZZ	PAGZZ	PAFZZ	D	.050	5310-00-052-3632	NUT, WASHER ASSEMBLY: TERMINAL BOARD MTG 69-561-3 30554 511-081800-00 78189	EA	4	54
8	60	PAOZZ	PAOZZ	PAGZZ	PAFZZ	D	.008	5305-00-984-6193	SCREW, MACHINE: TERMINAL BOARD MTG MS35206-245 96906	EA	4	15
8	61	XBOZZ	PAOZZ	PAHZZ	PAFZZ			5940-00-983-6105	TERMINAL BOARD 39TB10 81349	EA	1	1
8	62	PAOZZ	PAOZZ	XBGZZ	PAFZZ	D	.010	6150-00-665-7230	JUMPER, TERMINAL 602J 75382 69-651-3 30554	EA	3	3
8	63	PAFZZ	PAOZZ	PAGZZ	PAFZZ	D	.008	5310-00-094-3421	NUT, WASHER ASSEMBLY: RELAY MTG 511-101800-00 78189 69-561-4 30554	EA	4	8
8	64	PAFZZ	PAOZZ	PAGZZ	PAFFF		.700	6110-00-202-2888	RELAY ASSEMBLY 69-765 30554 30554-69-765 36024	EA	1	1
8	65	PAFZZ	PAOZZ	PAGZZ	PAFZZ		.050	5910-00-879-3478	CAPACITOR MS39016/02-1240 81349	EA	1	1
8	66	PAFZZ	PAOZZ	PAGZZ	PAFZZ	D	.008	5310-00-094-3421	NUT, WASHER ASSEMBLY 511-101800-0 78189 69-561-4 30554	EA	8	8



Current part is item (56) on diagram. Available at www.oshkoshequipment.com